



-
- 1 Prewash Hood 900mm
 - 2 Prewash Tank 900mm
 - 3 Prewash Column 900mm
 - 4 Corner hood
 - 5 Corner tank
 - 6 Drive unit
 - 7 Corner wash
 - 8 Rinse RCD
 - 9 Economiseur
 - 10 Ecorinse Hood 400mm
 - 11 Ecorinse Tank 400mm
 - 12 Ecorinse Column 400mm
 - 13 Control Box
 - 14 Springs-Thermostat
 - 15 Accessories
 - 16 Pumps spare parts
 - 17 Pump
 - 18 Hood 200mm
 - 19 Water counter/HPS EASY
 - 20 HPS EASY PLUS
 - 21 Solenoid valves
 - 22 Self cleaning
 - 23 Dryer 600
 - 24 Dryer on curve
 - 25 ARC
 - 26 Heat recovery unit
 - 27 Heat Recovery Unit
 - 28 Drain Pump




Code	Description
120342	DOOR MAGNETIC SWITCH
180160	HANDLE EKK.18 B-M4-C1
180662	AC2 RIGHT DOOR GUIDE
180663	AC2 RIGHT DOOR GUIDE AC2
190906	CURTAIN IN/OUT 620X480
190913	CURTAIN FOR ECORINSE SE-620X27
191120	HANDLE CAP
200978	GASKET
323600	DOOR BRACKET
323777	RACK GUIDE
323922	DOOR ACD900
323923	ACD900 DOOR EXTERNAL PANEL
324410	BACK BOARD
331973	DOOR MICRO SWITCH BRACKET
332336	BRACKET
332817	BRACKET
342152	DOOR SPRING SUPPORT
342934	SHAFT FOR CURTAIN AC2-AC2P
352214	LOWER BACK PANEL ACD900
352215	UPPER BACK PANEL ACD900
352604	FRONTAL PANEL ACD900
411001	PERMANENT MAGNET 8X40
440208	FOOT INSERT
440209	COMPLETE FOOT NE
621064	DOOR STOP LEVER ASSEMBLY AC2

Prewash Tank 900mm



01-2016 M. S.


Code	Description
161102	ELEMENT COVER MOPL. H50 (HIGH)
161310	AIR CHAMBER FOR GLASSWASHERS B
161312	HOSE FOR PRESSURE SWITCH C95-1
161408	OVERFLOW PIPE CAP
180108	PLASTIC NUT 1/2"
180159	HANDLE ELK.45 B-M6-C6
180248	SUCTION TANK
180249	NUT
180261	EXTENSION FOR 180248
180728V02	
180818	STRAINER FOR FC
190145	SUPPORT F.PAWL BAR GUIDE AC
190146	CLAMPING PIECES AC
200807	O-RING 3,53 X 110,72
200927	GASKET FOR AIR TRAP
260131	SCREW 6X45
260505	STAINL.STEEL FLAT WASHER D8
323808	TRAY GUIDE AC2E-900P
324194	GUIDE SUPPORT AC2
333034	FILTER 425X75 H90
333044	FILTER
333045	FILTER
342020	PIN
450143	CLAMP D.39,7 X 37,7
450516	THERMOSTAT SHIELD FOR 2 TERMOS
451002	COTTER PIN STAINL.ST. D2X12
510425	PAWL LOAD. AC/ACR
621068	TRAY GUIDE AC2E-900P




03 - 2013 M. S.

Prewash Column 900mm

Code	Description
160724	PLUG F. WASH ARM S90
180248	SUCTION TANK
190694	BUSH 1"1/4
190695	BUSH 1"3/4
200976	GASKET
200981	GASKET
201112	HOSE
201123	DELIVERY HOSE
324458	PUMP SUPPORT
333200	WASH COLUMN AC2
333205	WASH ARM AC2E-AC3
342156	LOWER WASH ARM SUPPORT
342162	WASH ARM SUPPORT AC2E-AC3
342169	FRONTAL SUPPORT
450107	CLAMP FE ZN 38-50 H=12,2




Code	Description
120342	DOOR MAGNETIC SWITCH
180160	HANDLE EKK.18 B-M4-C1
180662	AC2 RIGHT DOOR GUIDE
180663	AC2 RIGHT DOOR GUIDE AC2
190906	CURTAIN IN/OUT 620X480
191120	HANDLE CAP
323600	DOOR BRACKET
323920	DOOR ACD-600/900A
323921	1150 DOOR EXTERNAL PANEL
324195	COVER
331455	BRACKET FOR RINSE MICROSWITCH
331973	DOOR MICRO SWITCH BRACKET
332817	BRACKET
342152	DOOR SPRING SUPPORT
342174	LOWER SUPPORT
342934	SHAFT FOR CURTAIN AC2-AC2P
352204	SIDE PANEL
352210	SIDE LOWER PANEL AC2
352211	SIDE UPPER PANEL AC2
352212	BACK LOWER PANEL AC2A
352213	BACK LOWER PANEL AC2A
352616	LEFT FRONTAL PANEL
352617	RIGHT FRONT PANEEL
352618	FRONT PANEL
411002	PERMANENT MAGNET 24X12
440208	FOOT INSERT
440209	COMPLETE FOOT NE
621064	DOOR STOP LEVER ASSEMBLY AC2




11 - 2014 M. S.

Code	Description
110388	HEAT.ELEMENT 10000W 230/400V
160121	HOSE EPDM D. 5 X 9
160201	ELBOW F.TANK INLET MOPLN
161102	ELEMENT COVER MOPL. H50 (HIGH)
161324	AIR CHAMBER
161408	OVERFLOW PIPE CAP
161409	FILTER PLUG
180102	DRAIN PIPE NUT 1"1/2 F45-55
180108	PLASTIC NUT 1/2"
180159	HANDLE ELK.45 B-M6-C6
180248	SUCTION TANK
180249	NUT
180728	OVERFLOW PIPE
180818	STRAINER FOR FC
200412	GASKET DRAIN 1 1/2" 45X33X3
200815	O-RING F. HEAT. ELEM.
200927	GASKET FOR AIR TRAP
200950	VITON GASKET
260131	SCREW 6X45
333034	FILTER 425X75 H90
333044	FILTER
333045	FILTER
450115	ELASTIC CLAMP D.8,3/7,8
450516	THERMOSTAT SHIELD FOR 2 TERMOS




Code	Description
160947	
160948	
180254	FLANGE
180255	COUNTERFLANGE
180256	FLANGE COVER
190165	SUPPORT
190166	UPPER SUPPORT
190692	BUSH H370SM-3034-30
190699	BUSH
191126	BUSH
191148/R	BUSH KIT AC2
200872	O-RING 23X3,60
200873	GASKET 110,72X117,78X3,53
200877	GASKET OR 156 DI52.39 T3.53 NB
200979	GASKET
260505	STAINL.STEEL FLAT WASHER D8
323784	TRAY GUIDE
323789	EXTERNAL GUIDE
323790	INTERNAL GUIDE
323791	EXTERNAL GUIDE
323792	INTERNAL RACK GUIDE
324416	
324417	
324418	
324419	RAIL SUPPORT ACD AC2A
324420	FRONTAL WASH ARM SUPPORT AC2A
332615	FLANGE
332665	ECCENTRIC FLANGE DRIVE SHAFT
342020	PIN
342163	SUPPORT
342164	SUPPORT
342165	SUPPORT
342166	RACK GUIDE SUPPORT
342167	SUPPORT
342168	SIDE SUPPORT
342926	TRAINING SHAFT AC2
451002	COTTER PIN STAINL.ST. D2X12
510425	PAWL LOAD. AC/ACR
621077	LEFT CORNER TRAY GUIDE
621078	RIGHT CORNER TRAY GUIDE




03 - 2013 M. S.

Code	Description
160724	PLUG F. WASH ARM S90
190694	BUSH 1"1/4
190695	BUSH 1"3/4
200976	GASKET
200981	GASKET
201113	DELIVERY HOSE
324198	AC2-AC2P PUMP SUPPORT
333200	WASH COLUMN AC2
333205	WASH ARM AC2E-AC3
342162	WASH ARM SUPPORT AC2E-AC3
342169	FRONTAL SUPPORT
342173	FRONTAL SUPPORT
450107	CLAMP FE ZN 38-50 H=12,2




04/2013 M. S.

Code	Description
110388	HEAT.ELEMENT 10000W 230/400V
160108	INJECT.INLET HOSE D.8X5
161316	AIR TRAP
180332	NIPPEL 3/4"X12
180420	TEE-NIPPLE
191142	BREAK TANK AC2-AC3
200122	HOSE 11X19
200815	O-RING F. HEAT. ELEM.
201070	HOSE
201076	HOSE
330376	BOILER D150
450103	CLAMP FE ZN. 13-20 H=9
450105	CLAMP FE ZN. 26-38 H=12,2
450134	ELASTIC HOSE CLIP D.9,3/8,8
450149	CLAMP D.34,6 X 36,4
450150	CLAMP 820X8.9
460442	
621052	VACUUM BREAKER




12 - 2012 M. S.

Code	Description
120342	DOOR MAGNETIC SWITCH
191019	MAGNET HOUSING S90 MOPL.-S.N.L
191123	RAIL
260133	SCREW 10X55
260407	STAINLESS STEEL NUTS D10 UNI 5
320698	LEVER FOR ECONOMIZER SE SNL
331455	BRACKET FOR RINSE MICROSWITCH
332820	BRACKET
341255	PIN FOR ECONOMIZER SE SNL
411001	PERMANENT MAGNET 8X40
450294	




Code	Description
120342	DOOR MAGNETIC SWITCH
180160	HANDLE EKK.18 B-M4-C1
180662	AC2 RIGHT DOOR GUIDE
180663	AC2 RIGHT DOOR GUIDE AC2
190913	CURTAIN FOR ECORINSE SE-620X27
191120	HANDLE CAP
200978	GASKET
323600	DOOR BRACKET
323795	RACK GUIDE AC2-400E
323935	400 DOOR EXTERNAL PANEL
323936	DOOR 400 AC2
324195	COVER
324196	BOILER SUPPORT
324410	BACK BOARD
330715	UPPER BRACKET CURTAIN SNL-SE
331973	DOOR MICRO SWITCH BRACKET
332817	BRACKET
342934	SHAFT FOR CURTAIN AC2-AC2P
352204	SIDE PANEL
352220	LOWER BACK PANEL AC2-400E
352221	UPPER BACK PANEL AC2-400E
352606	FRONTAL PANEL AC2-400E
411002	PERMANENT MAGNET 24X12
440208	FOOT INSERT
440209	COMPLETE FOOT NE
621058	TRAY GUIDE AC2/400E
621064	DOOR STOP LEVER ASSEMBLY AC2



Ecorinse Tank 400mm


Code	Description
170719	OVERFLOW PIPE ACD900
200759	DELIVERY HOSE FOR ECORINSE AC-
200917	GASKET FOR OVERFLOW PIPE BR-BC
200963	JOINT 110X88X3
201001	HOSE FOR DRAIN PUMP LF
324421	PUMP SUPPORT AC2-400E
331647	JOIN BRACKET
333039	ECORINSE FILTER
450105	CLAMP FE ZN. 26-38 H=12,2
450107	CLAMP FE ZN 38-50 H=12,2
450114	CLAMP FE ZN.22-32 H=12,2
621073	



04 - 2016 M. S.

Ecorinse Column 400mm

Code	Description
161113	ELMENT COVER BLACK
180101	RETAIN.NUT 3/4" B23-10-11-12
200122	HOSE 11X19
200480	GASKET F. RINSE CONNECT.
200759	DELIVERY HOSE FOR ECORINSE AC-
200809	OR GASKET 1,78X8,73X12,29
200815	O-RING F. HEAT. ELEM.
280525	NIPPLE
290105	BRASS-TE-PLUG 1/2"
330322	INSULATED BOILER D.230 N/S
380317	RINSE JETS OV 1/8" 303 125LT 8
380323	RINSE JETS 37.5 80? OV 1/8
430181	ECORINSE ARM AC
430243	RINSE ARM ACS 122
450103	CLAMP FE ZN. 13-20 H=9
450104	CLAMP FE ZN H=12,5 15-24
450150	CLAMP 820X8.9
450516	THERMOSTAT SHIELD FOR 2 TERMOS
451123	ELASTIC PIN 4X16
460444	INSULATION PANEL
460502	GASKET 30X21X2
460503	SEALING WASHER 38X27X2(3/4)
510403	CONNECT.HOSE 90?1/2"X12
ACR185	RINSE COLUMN




Asciugatura - Sechage - Dryer - Trocknung - Secado

220/240 V					380/415 V			
KW	A	Fusibili Fusible Fuse Schmelzsicherung Fusible	A	Teleruttore Contacteur Contactor Schaltschütz Contactor	A	Fusibili Fusible Fuse Schmelzsicherung Fusible	A	Teleruttore Contacteur Contactor Schaltschütz Contactor
6	20	130248	12	120429	12	130246	12	120429
9	25	130236	25	120437	16	130247	25	120437

08 - 2014 M.S.A.

Code	Description
120429	CONTACTOR 12A 24V 50HZ
120437	CONTACTOR 25A 24V 50HZ
120445	AUXILIARY RELAY S.B2/3 24V
120468	CONTACTOR ABB 9A 24V 50/60HZ
120469	CONTACTOR ABB 12A 24V 50/60HZ
120471	CONTACTOR ABB 26A 24V 50/60HZ
120493	RELAY 130180240000
120496	RELAY ABB E256-24
120648	TRANSFORMER 250VA225-240-380-4
120649	TRANSFORMER 300VA225-240-380-4
120650	TRANSFORMER 400VA225-240-380-4
120651	TRANSFORMER 500VA225-240-380-4
120745	MAIN SWITCH 4 POLE 125A
120748	MAINSWITCH 80A 4P
120749	MAINSWITCH 63A 4P
120858	OVERLOAD RELAY ABB 0,4-0,63A
120859	OVERLOAD RELAY ABB 0,63-1A
120863	OVERLOAD RELAY ABB 2,8-4A
120864	OVERLOAD RELAY ABB 4,5-6,5A
121020	CIRCUIT BREAKER 20A
121021	CIRCUIT BREAKER 25A
121022	CIRCUIT BREAKER 32A
121023	CIRCUIT BREAKER 40A
121024	CIRCUIT BREAKER 50A
121025	CIRCUIT BREAKER 63A
121026	MAGN.SWITCH 80A
121314	PCB uniAPRS-104 24V
121326	INVERTER ATV12H018M2
121327	INVERTER ATV12H037M2
130236	FUSE 14X51 25A GF14325
130246	FUSE 10.3X38 12A GF13312
130247	FUSE 10.3X38 16A GF13316
130248	FUSE 20A-10,3X38 13320 G.F.
130925	CONTACT FOR CIRCUIT BREAKER
130928	CONTACT ABB 4NO
150227	BRACKET
150710	FUSE CARRIER 10,3X38 ART.21401
200432	SPONGY RUBBER ADHESIV 8X4 NEOP
260201	SCREW TCP 3X10
260223	M5X12 MSH/HD SCREW SPECIAL S/S
260401	NUT 3MA
260403	NUTS D.5
260404	STAINLESS STEEL NUTS D6 UNI 55
260503	STAINL.STEEL FLAT WASHER D5 UN
260509	GROWER WASHER D.3

Code	Description
260512	ST/ST GROWER WASHER D6
260518	FLAT WASHER
261011	SCREW M5
331960	BRACKET
630977	COIL FOR CIRCUIT BREAKER 24V



Code	Description
120501	THERMOSTAT 30/90°C
120519	SAFETY THERMOSTAT 95-125°C
161127	BOX FOR THERMOSTAT
191040	FRAME F.THERMOSTAT KNOB
200491	BACK GASKET OF THERMOSTAT BOX
391323	SPRING KG 2.5
391324	SPRING KG 3
391325	SPRING KG 3.5
391326	DOOR SPRING KG 4.0
391329	SPRING KG 5.5
391337	SPRING KG 8
450315	KNOB F. THERMOSTAT 90°C

130620
1" LIV (145-80)
2" LIV (50-30)
3" LIV (50-30)

130629
(2B-12)
- ECORINSE
- MULTIRINSE (X2)

RCD

332470

130605
(45-30)
SL13a

130628
1" LIV (110-70)
2" LIV (50-30)
3" LIV (50-30)
SL13b
SL13c

410607 Standard
(VF49L 1F1-60P71B5B3)

410608
(VF49L 1F1-45P71B5B3)

410609
(VF49L 1F1-36P71B5B3)

100133 Standard
(0.18 kW 6-8P)
100131 (0.18 kW 4-6 P)
100135 (0.18 kW 4 P)

200815
161102

4,2 kW	110331
5 kW	110371
6 kW	110349
7 kW	113500
8 kW	110343
9 kW	110362
10 kW	110388
11 kW	113501
12 Kw	113502
12,5 Kw	110367



440828
342929
180257

180257
440828

391323 (Kg2)
391324 (Kg3)
391325 (Kg3.5)

391326 (Kg4)
391327 (Kg4.5)
391328 (Kg5)
391329 (Kg5.5)
391337 (Kg6)

Code	Description
100131	DRIVE MOTOR 4/6P 400V
100133	MOTOR 0.18KW 6-8POLI400V/3/50
100135	MOTOR 4P 0.18KW 230/400/50/3
110331	HEAT.ELEMENT 4200W 230/400V
110343	HEAT.ELEM. 8000W 220/380V
110349	HEAT.ELEMENT 6000W 230/400V
110362	HEAT.ELEMENT 9000W 220/380V
110367	HEAT.ELEMENT 12500W 230/400V
110371	HEAT.ELEMENT 5000W 220/380V
110388	HEAT.ELEMENT 10000W 230/400V
113500	7000W HEATING ELEMENT
113501	HEAT. ELEMENT 11KW 230/400V
113502	HEATING ELEMENT 12000W.230/400
130605	PRESSURE SWITCH 50-30 1 LEVEL
130620	PRESSURE SWITCH 3 LEVEL 50-30/
130628	PRESSURE SWITCH
130629	PRESSURE SWITCH 1L30-12
161102	ELEMENT COVER MOPL. H50 (HIGH)
180257	DOOR SPRING SIDE FLANGE
200815	O-RING F. HEAT. ELEM.
332470	PRESSURE SWITCH SUPPORT
342929	DOOR SPRINGS PIN
391323	SPRING KG 2.5
391324	SPRING KG 3
391325	SPRING KG 3.5
391326	DOOR SPRING KG 4.0
391327	SPRING KG 4,5
391328	SPRING KG 5
391329	SPRING KG 5.5
391337	SPRING KG 8
410607	REDUCER VF49L1F1-60P71B5B3
410608	REDUCER VF49L1F1-45P71B5B3
410609	REDUCER .VF49L1F1-36P71B5B3
440828	RING BENZING 7 DIN6799 INOX



12 - 2015 M. S.

Code	Description
100902	PUMP 0,85KW ZF522DX 230/50/1
100912	PUMP 0.6KW ZF210APSX 230/50/1
100913	PUMP 0.6KW ZF210V 230/50/1
100914	PUMP 1,24KW 230-400V/3/50HZ
100920	PUMP 0,85KW ZF522DX 230V/1/50
100930	PUMP 0,85KW ZF522DX 230/1/50
630137	PUMP VOLUTE LGB ZF800DX
630149	PUMP VOLUTE
630150	PUMP VOLUTE
630151	PUMP VOLUTE
630152	PUMP VOLUTE
630421	GASKET LGB 0,30 HP
630422	JOINT LOWARA 0,9KW
630426	GASKET LGB ZF800
630433	GASKET FOR PUMP 100827
630435	PUMP GASKET
630541	SEAL FOR PUMP 100827
630546	SEAL FOR PUMP
630547	SEAL FOR PUMP
631202	CONDENSER 16 MF 450V
631207	CONDENSER 12,5MF. 450V 85C
631220	CONDENSER 14 MF
631717	PUMP IMPELLER
631718	PUMP GASKET
631719	PUMP IMPELLER
631720	PUMP IMPELLER
631722	IMPELLER ZF522 -----60hZ
632507	PUMP IMPELLER
632508	PUMP IMPELLER D.67

1150 AC2

100902
230/1/50hz (kW 0,85)


100902V01
230/1/60hz (kW 0,85)

100902V02
440/3/60hz (kW 0,85) INOX

100902V03
400/3/50hz (kW 0,85) INOX

100902V04
230/1/50hz (kW 0,85) INOX

100902V05
400/3/60hz (kW 0,85) INOX



100914
230-400/3/50hz (kW 1,24)

100914V01
230-400/3/60hz (kW 1,24)

100914V02
230-400/3/50hz (kW 1,24) INOX

100914V03
440/480/3/60hz (kW 1,24)

AC2A



1150 (AC2E...-AC3)

100914
230-400/3/50hz (kW 1,24)

100914V01
230-400/3/60hz (kW 1,24)

100914V02
230-400/3/50hz (kW 1,24) INOX

100914V03
440/480/3/60hz (kW 1,24) INOX




900

100914
230-400/3/50hz (kW 1,24)

100914V01
230-400/3/60hz (kW 1,24)

100914V02
230-400/3/50hz (kW 1,24) INOX


100914V03
440/480/3/60hz (kW 1,24) INOX



900 MR

100910
230/1/50hz (kW 0,48)

100910V01
230/1/60hz (kW 0,48)



PWS

100920
230/1/50hz (kW 0,85)

100920V01
230/1/60hz (kW 0,85)

100920V02
440/3/60hz (kW 0,85)

100920V03
400/3/50hz (kW 0,85)

100920V04
230/1/50hz (kW 0,85) INOX

100920V05
400/3/60hz (kW 0,85)

100930
230/1/50hz (kW 0,85)


100930V01
230/1/60hz (kW 0,85)

100930V02
440/3/60hz (kW 0,85)

100930V03
400/3/50hz (kW 0,85)

100930V04
230/1/50hz (kW 0,85) INOX

100930V05
400/3/60hz (kW 0,85)




RCD

100912
230/1/50hz (kW 0,52)

100912V01
230/1/60hz (kW 0,52)

100912V03
400/3/50hz (kW 0,52)



600/DHM

100913
230/1/50hz (kW 0,99)

100913V01
230/1/60hz (kW 0,99)

100913V02
440/1/60hz (kW 0,99)

100913V03
400/3/50hz (kW 0,99)

100913V04
230/1/50hz (kW 0,99) INOX

100913V05
400/3/60hz (kW 0,99)

100913V06
480/3/60hz (kW 0,99)


500

400


100910
230/1/50hz (kW 0,48)

100910V01
230/1/60hz (kW 0,48)


MS 07-2015




Code	Description
100902	PUMP 0,85KW ZF522DX 230/50/1
100902V01	PUMP 0,85kW ZF522DX 230V/1/60
100902V02	PUMP 0,85 kW ZF522DX 440V/3/60
100902V03	PUMP 0,85KW ZF522DX 400V/3/50
100902V04	PUMP 0,85kW ZF522AIDX 230/50
100902V05	PUMP 0,85KW ZF522DX 400V/3/60
100910	PUMP 0.48KW 230/50/1
100910V01	PUMP 0.48KW 230/60/1
100912	PUMP 0.6KW ZF210APSX 230/50/1
100912V01	PUMP 0.5KW ZF210APSX 230/60/1
100912V03	PUMP 0.5kW ZF210APSX 400/3/50
100913	PUMP 0.6KW ZF210V 230/50/1
100913V01	PUMP 0.99 KW ZF210V 230V/1/60
100913V02	
100913V03	PUMP 0.99kW ZF210V 400V/3/50
100913V04	PUMP 0.99kW 230V/1/50Hz INOX
100913V05	PUMP 0.99kW ZF210V 400V/3/60
100913V06	PUMP 0.99kW ZF210V 480V/3/60
100914	PUMP 1,24KW 230-400V/3/50HZ
100914V01	PUMP 1.24kW 230-400V/3/60Hz
100914V02	PUMP 1.24kW230-400V/3/50 INOX
100914V03	PUMP 1.24kWZF650 440-480/3/60
100920	PUMP 0,85KW ZF522DX 230V/1/50
100920V01	PUMP 0,85KW ZF522DX 230/1/60
100920V02	PUMP 0,85KW ZF522DX 440/3/60
100920V03	PUMP 0,85KW ZF522DX 400/3/50
100920V04	PUMP 0,85KW ZF522AIDX 230/50
100920V05	PUMP 0,85KW ZF522DX 400/3/60
100930	PUMP 0,85KW ZF522DX 230/1/50
100930V01	PUMP 0,85KW ZF522DX 230/1/60
100930V02	PUMP 0,85KW ZF522DX 440/3/60
100930V03	PUMP 0,85KW ZF522DX 400/3/50
100930V04	PUMP 0,85kW ZF522AIDX 230/50
100930V05	PUMP 0,85KW ZF522DX 400V/3/60



Code	Description
120713	SWITCH 15 AMP FIVE-POLE 361552
120743	
120744	SWITCH QUADRIPOLE.16A 380V
121296	ELECTRONIC CONTROL PANEL
121340	WATER COUNTER PCB
130411	START CONTACT YELLOW
130476	ROTATIVE EMERGENCY SWITCH
180129	NUT FOR MAIN SWITCH SUPPORT
180847	NAME EMERGENCY-STOP
190160	SUPPORT
191168	SUPPORT
191169	SUPPORT
323849	RACK GUIDE
343576	HOOD
343594	HOOD
343594/20	BACK LOWER PANEL
343594/22	FRONT LOWER PANEL
343598	HOOD
352613	BACK PANEL
352614	FRONT PANEL
450316	CONTROL KNOB TWO COLOURS B-BT-
461545	RED PLATE AC2 TECH
461546	BLUE PLATE AC2
461561	BLACK PLATE AC3
461564	





Code	Description
113603	CABLE L=4000 mm
113604	CABLE HPS EASY/RS232
113605	CABLE HPS EASY/PROBES NTC
113606	CABLE HPS EASY/ENERGY COUNTER
113607	CABLE HPS EASY/WATER COUNTER
120960	PROBE C-G
120974	ENERGY COUNTER
121330	FLUXMETER 1/4"G 300L/H
121335	PCB 24VAC HPS EASY
121340	WATER COUNTER PCB
461547	RED PLATE
461548	BLUE PLATE
461556	HPS EASY RED PLATE
461557	BLUE PLATE HPS EASY



8-2015



Code	Description
113603	CABLE L=4000 mm
113605	CABLE HPS EASY/PROBES NTC
113605V01	CABLE HPS EASY/SONDE NTC L=11m
113605V02	CABLE HPS EASY/SONDE NTC L=5m
113606	CABLE HPS EASY/ENERGY COUNTER
113607	CABLE HPS EASY/WATER COUNTER
120641	SAFETY TRANSFORMER 30VA
120974	ENERGY COUNTER
121330	FLUXMETER 1/4"G 300L/H
121336	PCB DWCORE HPS EASY PLUS
121340	WATER COUNTER PCB
130610	PRESSURE SWITCH 1 LEVEL 110-85
130611	PRESSURE SWITCH FOR GLASSWASHE




MS. 12-12

Solenoid valves

Code	Description
121178	SOLENOID VALVE 01.010.125
121179	FILTER
121180	2-VALVES CONNECTOR
121181	BRACKET
121182	"T" CONNECTION
121183	SOLENOID VALV.01.010.125 X PRS
281102	1/2" ADJ VALVE C/W GAUGE TYPE
352248	SIDE PANEL
461550	LABEL "HOT WATER"
461550/1	LABEL "COLD WATER"




Code	Description
121178	SOLENOID VALVE 01.010.125
121182	"T" CONNECTION
180413	TEE NIPPLE D.11,5 - RINSE ASSE
200122	HOSE 11X19
450103	CLAMP FE ZN. 13-20 H=9
621052	VACUUM BREAKER




MS.03-16

Code	Description
100560	FAN ZIEHL 0.42
110704	HEAT.ELEMENT/DRYING 1000W 220V
190145	SUPPORT F.PAWL BAR GUIDE AC
190146	CLAMPING PIECES AC
190906	CURTAIN IN/OUT 620X480
323783	RACK GUIDE ACD600
323794	CHANNEL F.DRIVE BEARING
323797	GUIDE 600
324194	GUIDE SUPPORT AC2
340387	PANEL
342179	SUPPORT
342180	SUPPORT
342934	SHAFT FOR CURTAIN AC2-AC2P
343587	HOOD
352910	FRONT PANEL X DPC AC2-600D
450515	STAINL.ST.SHIELD FOR 1 THERMOS
510425	PAWL LOAD. AC/ACR
621063	
ACR253/B	LOWER DREYER AS ACE
ACR345	FRONT ELEMENT SUPPORT
ACR346	BACK ELEMENT SUPPORT
ACR347	DRYER VENTILATOR SUPPOR




Code	Description
100560	FAN ZIEHL 0.42
110704	HEAT.ELEMENT/DRYING 1000W 220V
110706	DRYER HEAT.ELEMENT 1500W 230V
120501	THERMOSTAT 30/90°C
120519	SAFETY THERMOSTAT 95-125°
140101	BRASS CONNECT. PLATE HEAT.ELEM
161127	BOX FOR THERMOSTAT
190906	CURTAIN IN/OUT 620X480
191040	FRAME F.THERMOSTAT KNOB
200491	BACK GASKET OF THERMOSTAT BOX
270101	HEXAGON LOCK NUT 1/2"
331707	BRACKET
340422	SHAFT FOR CURTAIN AC-ACR
342585	HOOD
450315	KNOB F. THERMOSTAT 90°
450515	STAINL.ST.SHIELD FOR 1 THERMOS
ACR024/A	PANNELLO LATERALE AS TESTA ACE
ACR069	BRACKET
ACR253/B	LOWER DREYER AS ACE
ACR315	
ACR345	FRONT ELEMENT SUPPORT
ACR346	BACK ELEMENT SUPPORT
ACR347	DRYER VENTILATOR SUPPOR
ACR387	





01 - 2015 M. S.

Code	Description
100550	FAN FOR HEAT RECOVERY UNIT
100560	FAN ZIEHL 0.42
110704	HEAT.ELEMENT/DRYING 1000W 220V
120519	SAFETY THERMOSTAT 95-125?
161127	BOX FOR THERMOSTAT
190906	CURTAIN IN/OUT 620X480
190913	CURTAIN FOR ECORINSE SE-620X27
200491	BACK GASKET OF THERMOSTAT BOX
330715	UPPER BRACKET CURTAIN SNL-SE
332846	BRACKET
340422	SHAFT FOR CURTAIN AC-ACR
400817	BATTERY FOR STEAM CONDENSER +
400819	HRU BATTERY
440208	FOOT INSERT
440209	COMPLETE FOOT NE
621052	VACUUM BREAKER
ACR023/A	CASSONE RC INTERNO AS ACE
ACR024/A	PANNELLO LATERALE AS TESTA ACE
ACR025/B	PANNELLO ANT.POST.AS
ACR027/A	TRAVERSA PANNELLI AS ACRS2
ACR028/A	TRAVERSA AGG.PANN.AS ACE
ACR029	800 DRYER COVER
ACR069	BRACKET
ACR071	COVER
ACR211/B	PARATIA ASP.ARIA.AS
ACR214	800MM DRYER FRONT INSUL.PANEL
ACR215	800MM DRYER BACK INSUL.PANEL
ACR253/B	LOWER DREYER AS ACE
ACR255/A	COVER
ACR278	
ACR315	
ACR341	SUPPORTO BATTERIA RC DA 21 ACE
ACR387	




MS. 09-13

Code	Description
100562	FAN W1G172-EC91-01
100563	VENTILATOR A2E170AF2315
270311	NIPPLE 3/4"-1/2"
310402	PLUG 3/4"
370459/1	BASEMENT
370459/10	CAP
370459/11	INVITATION SPLASH GUARD
370459/12	DEFLETTORE PARASPRUZZI RC
370459/2	SIDE PANEL
370459/3	BATTERY PANEL
370459/4	CHANNEL DEVIATION AIR
370459/5	UPPER COVER
370459/6	COVER REGULATION AIR
370459/7	SPLASH GUARD FOR RC400mm
400817	BATTERY FOR STEAM CONDENSER +
510403	CONNECT.HOSE 90°1/2"X12
621052	VACUUM BREAKER



Heat Recovery Unit

Code	Description
100562	FAN W1G172-EC91-01
100563	VENTILATOR A2E170AF2315
100563R	REPLACEMENT KIT 100562
161209	CASE 80 X 80 X 40 IP 44
370459/8C	COLLAR.ADATT.VENT.RC OLD-NEW
631219	CONDENSATOR 1,5 MF 400V



01-2016 MS

Code	Description
100695	DRAIN PUMP 220V-50
120445	AUXILIARY RELAY S.B2/3 24V
121242	TIMER LAV1000
200320	DRAIN PUMP HOSE
200346	DRAIN HOSE GLASSWASHER
201076	HOSE
324307	COVER FOR DRAIN PUMP
324425	SUPPORT FOR DRAIN PUMP
450107	CLAMP FE ZN 38-50 H=12,2
450114	CLAMP FE ZN.22-32 H=12,2
621059	COMPLETE DRAIN MANIFOLD