

PARTI DI RICAMBIO
PIECES DETACHEES
SPARE PARTS
ERSATZTEILE
LISTA DE RECAMBIOS

BHC 25
BHC 25 A
BHC 30
BHC 30 A
BHC 433
BHC 433 A


09/99



01 - 2000 S. AG.

- 1 Hood
- 2 Hood
- 3 Tank
- 4 Tank
- 5 Wash arm
- 6 Rinse assembly
- 7 Rinse assembly
- 8 Wash pump
- 9 Wash pump
- 10 Control-box BHC433
- 11 Rinse aid injector
- 12 Rack
- 13 Detergent dispenser
- 14 Drain pump


sino alla matricola - jusqu'à la matr. - up to serial no. - bis Seriennr. - hasta la matr. **9400/08/01**



Code	Description	Price (€)
150838	CABLE HOLDER FOR BHC	
160542	SCREW SUPPORT	
160720	PLUG HEYCO D.8	
160784	PLUG	
160787	NUT	
160788	PLUG	
160789	NUT	
160838	SLIDING WASHER TIE ROD FC	
160905	SLIDING PLATE F. TIE ROD	
180506	DOOR CATCH BR-BC-FC	
190619	DOOR CATCH B-F-R	
190657	RACK STOP BHC	
200415	AIR TRAP GASKET -F2 18,5X10X3	
200433	SPONGY RUBBER RECT. 6X2,5 ADHE	
200868	GASKET	
200943	GASKET	
200945	DOOR GASKET BHC	
210207	FOOT BHC	
260104	STAINL.ST TE-SCREW A2 6X16 UNI	
260138	SCREW TE 4X10	
260139	SCREW TE 5X16	
260238	M4 X 10 MUSH/HD SCREW	
260323	SCREW TSP 5X20	
260326	SCREW TS 5X10	
260404	STAINLESS STEEL NUTS D6 UNI 55	
260414	SELF-LOCKING NUT M5	
260418	SELF-LOCKING NUT M4	
260503	STAINL.STEEL FLAT WASHER D5 UN	
260512	ST/ST GROWER WASHER D6	
260712	SCREW 2,9X9,5	
260713	SCREW 3,9X16	
260714	SCREW 4,2X19	
261013	SCREW	
261015	SCREW 3,9X13	
322335	COVER BHC	
322644	RACK GUIDE BHC	
323006	DOOR BHC25	
323007	DOOR BHC30	
330235	ROD FOR BHC DOOR	
342087	PIN	
342701	PIN FOR TIE ROD	
351377	LEFT PANEL BHC25	
351379	LEFT PANEL	
351393	RIGHT PANEL BHC25/1	
351409	LATERAL PANEL	

Code	Description	Price (€)
351702	FRONT PANEL	
351911	PANEL	
351912	BACK PANEL BHC30	
390175	PANEL	
411010	DOOR MAGNET	
450234	SPRING	
450821	SPRING CLIP FASTENER SNU 3634	
450829	DOOR BRACKET BHC	
450831	SCREW SUPPORT	
463138	NAME PLATE	
463139	NAME PLATE	
463140	NAME PLATE	
463141	NAME PLATE	
463145	NAME PLATE	
463146	NAME PLATE	


dalla matricola - a partir de la matr. - from serial no. - ab Seriennr. - despues la matr. **9401/09/01**



Code	Description	Price (€)
150838	CABLE HOLDER FOR BHC	
160542	SCREW SUPPORT	
160720	PLUG HEYCO D.8	
160755	PLUG FOR MACHINES WITHOUT SOFT	
160788	PLUG	
160789	NUT	
160838	SLIDING WASHER TIE ROD FC	
160905	SLIDING PLATE F. TIE ROD	
180506	DOOR CATCH BR-BC-FC	
190619	DOOR CATCH B-F-R	
190657	RACK STOP BHC	
200415	AIR TRAP GASKET -F2 18,5X10X3	
200433	SPONGY RUBBER RECT. 6X2,5 ADHE	
200489	GASKET 81X68X3	
200943	GASKET	
200945	DOOR GASKET BHC	
210207	FOOT BHC	
260104	STAINL.ST TE-SCREW A2 6X16 UNI	
260138	SCREW TE 4X10	
260139	SCREW TE 5X16	
260238	M4 X 10 MUSH/HD SCREW	
260323	SCREW TSP 5X20	
260326	SCREW TS 5X10	
260404	STAINLESS STEEL NUTS D6 UNI 55	
260414	SELF-LOCKING NUT M5	
260418	SELF-LOCKING NUT M4	
260503	STAINL.STEEL FLAT WASHER D5 UN	
260512	ST/ST GROWER WASHER D6	
260712	SCREW 2,9X9,5	
260713	SCREW 3,9X16	
260714	SCREW 4,2X19	
261013	SCREW	
261015	SCREW 3,9X13	
322335	COVER BHC	
322644	RACK GUIDE BHC	
323006	DOOR BHC25	
323007	DOOR BHC30	
330235	ROD FOR BHC DOOR	
342087	PIN	
342701	PIN FOR TIE ROD	
351392	LATERAL PANEL	
351393	RIGHT PANEL BHC25/1	
351408	LATERAL PANEL	
351409	LATERAL PANEL	
351715	FRONT PANEL	

Code	Description	Price (€)
351911	PANEL	
351912	BACK PANEL BHC30	
390175	PANEL	
411010	DOOR MAGNET	
450234	SPRING	
450821	SPRING CLIP FASTENER SNU 3634	
450829	DOOR BRACKET BHC	
450831	SCREW SUPPORT	
463138	NAME PLATE	
463139	NAME PLATE	
463140	NAME PLATE	
463141	NAME PLATE	
463145	NAME PLATE	
463146	NAME PLATE	


sino alla matricola - jusqu'à la matr. - up to serial no. - bis Seriennr. - hasta la matr. 9400/08/01



Code	Description	Price (€)
100760	PUMP HP 0,3 220/240 BHC	
110269	TANK HEATER 2000W	
120524	TANKTHERMOSTAT GLASSWASHER	
130629	PRESSURE SWITCH 1L30-12	
160121	HOSE EPDM D. 5 X 9	
160310	INLET HOSE BHC	
160769	PLUG F. UPPER WASH ARM SUPPORT	
161316	AIR TRAP	
161317	NUT FOR AIR TRAP	
180145	NUT	
180147	NUT	
180724	OVERFLOW PIPE BHC	
180725	OVERFLOW PIPE COVER	
180824	TANK STRAINER BHC	
190209	UPPER WASH/RINSE ARM SUPPORT "	
190223	LOWER WASH/RINSE ARM SUPPORT B	
190225	DRAIN OUTLET	
191083	LOWER WASH ARM SUPPORT	
200415	AIR TRAP GASKET -F2 18,5X10X3	
200494	GASKET FOR TANKTHERMOSTAT BT	
200779	DRAIN HOSE FOR BR-BC-FC43	
200805	OR GASKET 2,62X28,24X33,48	
200820	O-RING151 46,99X5,33X57,6	
200821	O-RING 2,62X20,63	
200842	SEAL RING OR158 PB701 NITRILE	
200867	GASKET	
200869	GASKET	
200944	GASKET	
201029	TANK INLET HOSE	
201030	OUTLET HOSE	
201032	OUTLET HOSE	
260103	SCREW TE 6X12	
260402	STAINLESS STEEL NUT D4 UNI 55	
260404	STAINLESS STEEL NUTS D6 UNI 55	
260502	S/S FLAT WASHER D.4	
260510	GROWER WASHER D.4	
260512	ST/ST GROWER WASHER D6	
260706	SCREW 3,9X13 S/S	
332029	PUMP FILTER BHC	
390522	BRACKET FOR PUMP HPO,12	
450104	CLAMP FE ZN H=12,5 15-24	
450107	CLAMP FE ZN 38-50 H=12,2	
450109	CLAMP 50-65	
450115	ELASTIC CLAMP D.8,3/7,8	
450139	CLAMP 26-38 H=9	



Code	Description	Price ()
450232	SPRING	

dalla matricola - a partir de la matr. - from serial no. - ab Serienr. - despues la matr. 9401/09/01




Code	Description	Price ()
100785	PUMP LGB ZF140 0.5HP	
110269	TANK HEATER 2000W	
120524	TANKTHERMOSTAT GLASSWASHER	
130629	PRESSURE SWITCH 1L30-12	
160121	HOSE EPDM D. 5 X 9	
160310	INLET HOSE BHC	
160769	PLUG F. UPPER WASH ARM SUPPORT	
161316	AIR TRAP	
161317	NUT FOR AIR TRAP	
180145	NUT	
180147	NUT	
180724	OVERFLOW PIPE BHC	
180725	OVERFLOW PIPE COVER	
180824	TANK STRAINER BHC	
190209	UPPER WASH/RINSE ARM SUPPORT "	
190223	LOWER WASH/RINSE ARM SUPPORT B	
190225	DRAIN OUTLET	
191083	LOWER WASH ARM SUPPORT	
200415	AIR TRAP GASKET -F2 18,5X10X3	
200494	GASKET FOR TANKTHERMOSTAT BT	
200779	DRAIN HOSE FOR BR-BC-FC43	
200805	OR GASKET 2,62X28,24X33,48	
200820	O-RING151 46,99X5,33X57,6	
200821	O-RING 2,62X20,63	
200842	SEAL RING OR158 PB701 NITRILE	
200867	GASKET	
200869	GASKET	
200944	GASKET	
201032	OUTLET HOSE	
201054	TANK INLET HOSE	
201059	OUTLET HOSE	
260104	STAINL.ST TE-SCREW A2 6X16 UNI	
260402	STAINLESS STEEL NUT D4 UNI 55	
260404	STAINLESS STEEL NUTS D6 UNI 55	
260502	S/S FLAT WASHER D.4	
260504	ST/ST FLAT WASHER D6	
260510	GROWER WASHER D.4	
260512	ST/ST GROWER WASHER D6	
260706	SCREW 3,9X13 S/S	
332029	PUMP FILTER BHC	
341879	BRACKET FOR PUMP	
450104	CLAMP FE ZN H=12,5 15-24	
450107	CLAMP FE ZN 38-50 H=12,2	
450109	CLAMP 50-65	
450115	ELASTIC CLAMP D.8,3/7,8	

Code	Description	Price ()
450139	CLAMP 26-38 H=9	
450232	SPRING	




01 - 1999 S. AG.

Code	Description	Price ()
140108	PLATE FOR WASH ARM	
160734	END PLUGS RINSE ARM	
160736	WASH ARM PLUG F45	
170946	RINSE JET/RINSE ARM B-F	
170956	WASH JET/WASH ARM B-F20	
190649	BUSH WASH ARM GLASSWASHERS	
200812	O-RING 1,78X17,17X20,73	
200843	O RING 2X13X17	
200844	O RING 2X9,5X13,5	
200845	O RING 109 2,62X9,13X14,37	
260711	SCREW 4,2X13 A2 DIN7972	
261009	RETAIN.SCREW FOR WASH-RINSE AR	
420531	PLASTIC WASH-RINSE ARM F20-B	
420551	UPPER WASH ARM GLASSWASHERS	




Code	Description	Price ()
110397	HEATER 3200W 230V/1	
110398	HEATER 5000W 230V/3	
120146	SOLENOID VALVE 180? TYPE 2 WAY	
120501	THERMOSTAT 30/90?C	
120526	SAFETY THERMOSTAT 2POLES	
160108	INJECT.INLET HOSE D.8X5	
160542	SCREW SUPPORT	
160715	COVER FOR RINSE AID CONTAINER	
160805	GASKET D.8	
180415	TEE NIPPLE DOUBLE "T"	
190106	RINSE AID CONTAINER SUPP. B23-	
190802	RINSE.AID CONTAINER B20-B41S	
191040	FRAME F.THERMOSTAT KNOB	
200122	HOSE 11X19	
200416	GASKET D. 3/4"	
200714	GLASSWASHER INLET HOSE	
200820	O-RING151 46,99X5,33X57,6	
201043	OUTLET HOSE	
260126	SCREW TE 5X12	
260138	SCREW TE 4X10	
260215	SCREW TCP 6X16	
260512	ST/ST GROWER WASHER D6	
260538	WASHER 18X6X1,5 ST/ST	
261015	SCREW 3,9X13	
280523	NIPPLE	
330353	BOILER BHC	
331482	BRACKET FOR 2 THERMOST. B-F20	
331994	BRACKET FOR SOLENOID VALVE BHC	
340484	SHAFT F. RINSE AID CONTAINER	
450102	CLAMP FE ZN 11-17 H=9	
450103	CLAMP FE ZN. 13-20 H=9	
450115	ELASTIC CLAMP D.8,3/7,8	
450315	KNOB F. THERMOSTAT 90?	
450812	SPRING FOR SPINDLE (CODE NO.34	
460535	GASKET FOR BOILER PLUG BHC	
620120	RINSE AID INJECTOR	
620209	INLET WATER FILTER	
620535	VACUUM BREAKER	
630969	COIL S4216 220/50HZ	





Code	Description	Price (€)
110397	HEATER 3200W 230V/1	
110398	HEATER 5000W 230V/3	
120146	SOLENOID VALVE 180? TYPE 2 WAY	
120501	THERMOSTAT 30/90?C	
120526	SAFETY THERMOSTAT 2POLES	
160108	INJECT.INLET HOSE D.8X5	
160542	SCREW SUPPORT	
160715	COVER FOR RINSE AID CONTAINER	
160805	GASKET D.8	
180415	TEE NIPPLE DOUBLE "T"	
190106	RINSE AID CONTAINER SUPP. B23-	
190802	RINSE.AID CONTAINER B20-B41S	
191040	FRAME F.THERMOSTAT KNOB	
200122	HOSE 11X19	
200416	GASKET D. 3/4"	
200714	GLASSWASHER INLET HOSE	
200820	O-RING151 46,99X5,33X57,6	
201043	OUTLET HOSE	
201055	HOSE	
260126	SCREW TE 5X12	
260138	SCREW TE 4X10	
260215	SCREW TCP 6X16	
260512	ST/ST GROWER WASHER D6	
260538	WASHER 18X6X1,5 ST/ST	
261015	SCREW 3,9X13	
280523	NIPPLE	
330353	BOILER BHC	
331482	BRACKET FOR 2 THERMOST. B-F20	
331994	BRACKET FOR SOLENOID VALVE BHC	
340484	SHAFT F. RINSE AID CONTAINER	
450102	CLAMP FE ZN 11-17 H=9	
450103	CLAMP FE ZN. 13-20 H=9	
450115	ELASTIC CLAMP D.8,3/7,8	
450315	KNOB F. THERMOSTAT 90?	
450812	SPRING FOR SPINDLE (CODE NO.34	
460535	GASKET FOR BOILER PLUG BHC	
620120	RINSE AID INJECTOR	
620209	INLET WATER FILTER	
620535	VACUUM BREAKER	
630969	COIL S4216 220/50HZ	

sino alla matricola - jusqu'à la matr. - up to serial no. - bis Seriennr. - hasta la matr. 9400/08/01



631216
(6,3 µ F)




100760 230 V 50 Hz HP 0,3



09 - 2001 S. AG.

Code	Description	Price ()
100760	PUMP HP 0,3 220/240 BHC	
630133	PUMP VOLUTE LGB 0,30HP	
630244	PUMP COVER LGB 0,30 HP	
630421	GASKET LGB 0,30 HP	
630524	SEAL FOR PUMP LGB0,30 HP	
631216	CAPACITOR 6.3 MF 450V	
631689	PUMPE IMPELLER LGB 0,30 HP	

dalla matricola - a partir de la matr. - from serial no. - ab Seriennr. - despues la matr. 9401/09/01




631208
 (5 µ F)



100785 230 V 50 Hz HP 0,3 Kw 0,37


09 - 2001 | S. AG.

Code	Description	Price ()
100785	PUMP LGB ZF140 0.5HP	
630135	PUMP VOLUTE LGB 0,30HP ZF140	
630248	PUMP COVER LGB 0,30HP ZF140	
630424	PUMP GASKET LGB 0,3HP ZF140	
630530	SEAL FOR PUMP LGB 0,3HP ZF140	
631208	CONDENSER 5MF.450V	
631695	PUMP IMPELLER 0,3HP LGB	









09 - 2001 | S. AG.

Code	Description	Price (€)
112677	WIRING FOR BHC433	
120292	TIMER 90/180"	
120346	DOOR MICROSWITCH WITH MAGNET	
120461	CONTACTOR ABB B6-30-01 220V	
120735	6 POLE SWITCH 15A 2 POS.	
130157	GREEN LED FOR BR-BC-C-SERIES -	
130310	TERMINAL BLOCK 3 POSITIONS	
130449	PUSH BUTTON BR-BC-FC	
130629	PRESSURE SWITCH 1L30-12	
130704	GREEN COLOUR.IND.LAMP COVER	
150833	CABLE HOLDER BC/BR	
160121	HOSE EPDM D. 5 X 9	
160733	BLANK PLATES	
190140	BUTTON HOLDER BR-BC-FC	
200945	DOOR GASKET BHC	
260245	SPECIAL SCREW TC 3,5X16	
260248	SPECIAL SCREW TB 5X12	
260501	STAINL.STEEL FLAT WASHER D3 UN	
260509	GROWER WASHER D.3	
260701	SCREW 3,5X9,5	
290824	DISTANCE PIECE FOR BR-BC-FC SW	
341716	SUPPORT FOR ELECTR. PANEL BR-B	
351809	CONTROL PANEL SUPPORT	
440817	SNAP RING LSCB/1853/17/00	
450115	ELASTIC CLAMP D.8,3/7,8	
450120	ZINC CLAMP FOR HOSE D. 7	
450137	COLLAR CONNECTION WITH BASE 31	
450323	KNOB FOR BC-BR-C95-C155	
450326	PUSH BUTTON "CYCLE" GREEN	
450332	COLD RINSE SWITCH	
461063	PLATE FC43	
631208	CONDENSER 5MF.450V	
631209	ANTI-NOISE FILTER	
631216	CAPACITOR 6.3 MF 450V	




02 - 2004 | S. AG.


Code	Description	Price ()
160714	PLUG FOR RINSE AID INJECTOR MO	
170701	LOCK NUT 1/2" F.INJECTOR	
180306	NIPPLE F.RINSE AID INJECTOR	
190107	COVER FOR RINSE AID DISPENSER	
190108	VOLUTE FOR RINSE AID DISPENSER	
190803	GASKET SUPPORT RING F.INJECT	
191018	FILTER SUPPORT RINSE AID INJEC	
200444	SUCTION VALVE RINSE INJECTOR	
200816	O-RING 2,5X59,2X64,2 RINSE INJ	
200825	O-RING 3X5X11 RINSE INJECTOR	
200861	O-RING 14X18X2	
260142	SCREW TE 4X16	
260213	SCREW TCP 5X25	
260402	STAINLESS STEEL NUT D4 UNI 55	
260404	STAINLESS STEEL NUTS D6 UNI 55	
260512	ST/ST GROWER WASHER D6	
330543	FILTER RINSE AID INJECTOR D.17	
340483	PISTON FOR RINSE AID DISPENSER	
381105	DIAPHRAGME DISC	
440405	GASKET FOR RINSE AID INJ.	
450214	SPRING RINSE AID INJECTOR	
620120	RINSE AID INJECTOR	
630614	DIAPHRAGM RINSE INJECTOR	




Code	Description	Price ()
520131	GLASS RACK 40x40 H270	
520611	INSERT FOR CHAMPAGNE GLASSES	
660234	UPPER INSERT FOR 16-25-36 GLAS	
660235	LOWER INSERT FOR 16-25-36 GLAS	
660519	2-PLACES CUTLERY HOLDER	
660712	BASE RACK 400X400	
660714	GLASS RACK (400X400)	



Code	Description	Price ()
160132	HOSE 5X7	
180726	STREINER FOR RINSE AID INJECTO	
200467	DUTRAL GASKET F. AIR TRAP	
200608	DETERGENT DISPENSER HOSE	
251213	INJECTOR S/S FOR DETERGENT IN	
260223	M5X12 MSH/HD SCREW SPECIAL S/S	
260403	NUTS D.5	
260408	S/S NUTS D.12	
260503	STAINL.STEEL FLAT WASHER D5 UN	
260511	GROWER WASHER D.5	
331913	BRACKET	
440632	DETERGENT INJECTOR	



650122



03 - 2001 S.AG.

Code	Description	Price ()
100342	DRAIN PUMP 100 W 220V	
120290	TIMER FOR DRAIN PUMP	
130157	GREEN LED FOR BR-BC-C-SERIES -	
130449	PUSH BUTTON BR-BC-FC	
130704	GREEN COLOUR.IND.LAMP COVER	
180142	CONNECTOR FOR DRAIN PUMP	
190140	BUTTON HOLDER BR-BC-FC	
200346	DRAIN HOSE GLASSWASHER	
200867	GASKET	
201039	INLET HOSE	
260103	SCREW TE 6X12	
260404	STAINLESS STEEL NUTS D6 UNI 55	
260512	ST/ST GROWER WASHER D6	
332305	DRAIN PUMP BRACKET BHC	
351809	CONTROL PANEL SUPPORT	
450107	CLAMP FE ZN 38-50 H=12,2	
450114	CLAMP FE ZN.22-32 H=12,2	
450135	CLAMP FE ZN. 44-56 H=12,2	
450328	DRAIN SWITCH	
461061	CONTROL PANEL	
650122	DRAIN PUMP KIT	