




**ESPLOSI PARTI DI RICAMBIO
SPARE-PARTS EXPLODED-VIEWS
ERSATZTEILE
EXPLOSIONS-ZEICHNUNGEN
VUES-ECLATEES PIECES DETACHEES**

LP051-10-000


LP053-10-000

LP051-10-100

(2000)






* OPTIONAL




* OPTIONAL


2a









* OPTIONAL







B. 237

13 01 09 (230V- 50Hz)
13 01 19 (230V- 60Hz)

**T. 173**

13 01 26 (230V- 50Hz)

13 01 33 (230V- 60Hz)



T. 175