





BTGDBM

Gas Bain-Marie



Spare Parts



Key N°	Part N°	Description
1	PABF900072	CROSS BAR SUPPORT FOR COLLECTOR
2	RTCP700003	WATER TAP
3	RTCP800033 (R)	SPARK PLUG
4	RTCP800034 (R)	PILOT BODY
5	VEDI MANUALE UGELLI	PILOT INJECTOR
6	RTCU700020 (R)	PIEZO LIGHTING
7	RTCU700324	FOOT
8	VEDI MANUALE UGELLI	INIECTOR
9	RTCU900005	C/NUT
10	RTCU900012	BICONE Ø10
11	RTCU900013	NUT Ø10
12	RTCU900014	BICONE Ø12
13	RTCU900015	NUT Ø12
14	RTCU900016	BICONE Ø 10
15	RTCU900017	NUT Ø10
16	RTCU900121	ELBOW
17	RTCU900337	INJECTOR SUPPORT
18	RTCU900384 (R)	LIGHTING CABLE
19	RTCU900474 (R)	THERMOCOUPLE
20	160021	RIGHT SIDE
21	160023	INOX BACK PANEL
22	160028	BRACKET TO FIX CONTROL PANEL
23	164371	TANK
24	160212	COMBUSTION CHAMBER
25	160214	WATER DISCHARGE TAP
26	160215	FLUE FRONT WALL
27	160217	REAR WALL
28	160220 (R)	GAS THERMOSTAT
29	160221	COLLECTOR
30	160222	WATER TAP FEEDING PIPE
31	160224	WATER DISTRIBUTOR
32	160223	WATER TAP FEEDING PIPE
33	160226	WATER DISCHARGE PIPE
34	160238	BURNER
35	163221	CHIMNEY GRILL
36	160319	LEFT SIDE
37	160341	TAP EXTENSION
38	160353	LEFT WATER TAP CREW
39	160354	RRIGHT WATER TAP CREW
40	160376	BRACKET TO SUPPORT PILOT

(R) = - Recommended spare parts

Key N°	Part N°	Description
41	160380	ROD GUIDE
42	163197	DASH BOARD
43	160399	BULB HOLDER
44	160470	DRAIN KNOB
45	162481+163087	(R) THERMOSTAT KNOB+RING
46	163114+163079	(R) TAP KNOP+RING
47	160507	BOTTOM TOP
48	160562	PILOT PIPE
49	160563	BURNER FEEDING PIPE
50	RTCU900019	NUT Ø6
51	RTCU900018	BICONE Ø6
52	RTCU800182	NUT Ø6
53	RTCU800183	BICONE Ø6
54	RTCU900215	FITTING FOR PILOT SPARK PLUG
55	RTCP800038	NUT FOR THERMOELEMENT

(R) = - Recommended spare parts