





**BCG15KI**  
Gas Kettle




**Spare Parts**



**HOBART**

BCG15KI

TAV. 980



| Key N° | Part N°       |     | Description                      |
|--------|---------------|-----|----------------------------------|
| 1      | GACP800065    | (R) | PILOT                            |
| 2      | PACP800212    |     | PILOT PIPE                       |
| 3      | RTCP800019    | (R) | TAP                              |
| 4      | RTCP800021    |     | NUT FOR TAP D.20                 |
| 5      | RTCP800020    |     | DOUBLE CONE D.20                 |
| 6      | RTCP800023    |     | DOUBLE CONE D.16                 |
| 7      | RTCP800022    |     | NUT FOR TAP D.16                 |
| 8      | RTCP800067    | (R) | LIMIT THERMOSTAT                 |
| 9      | RTCP800073    |     | THERMOCOUPLE FITTING             |
| 10     | RTCU700374    | (R) | THERMOCOUPLE                     |
| 11     | RTCU800335    |     | CENTRAL BURNER                   |
| 12     | RTCU900010    | (R) | ROUND SPARK                      |
| 13     | RTCU900018    |     | DOUBLE CONE D.6                  |
| 14     | RTCU800339    |     | NUT D.6                          |
| 15     | RTCU900215    |     | FITTING FOR PILOT SPARK PLUG     |
| 16     | 160452        |     | RAMP                             |
| 17     | 162481+163082 | (R) | TAP KNOB+RING                    |
| 18     | 164997        |     | BURNER FEEDING PIPE              |
| 19     | RTCU700020    | (R) | PIEZO IGNITION + NUT             |
| 20     | RTBF900013    |     | DOOR HINGE                       |
| 21     | RTCU600075    |     | ROBINET DE L'EAU                 |
| 22     | RTCP800024    |     | WATER DISTRIBUTOR                |
| 23     | RTCP800026    |     | HINGE SPRING                     |
| 24     | RTCP800064    |     | SAFETY VALVE                     |
| 25     | RTCP700003    |     | WATER TAP                        |
| 26     | RTCP800163    |     | PIPE FLEXIBLE                    |
| 27     | RTCP800065    |     | LEVEL COCK                       |
| 28     | RTCP900004    |     | WATER DISCHARGE TAP              |
| 29     | RTCP900018    |     | BOSS                             |
| 30     | 161827        |     | THERMOMETER                      |
| 31     | 160028        |     | BRACKET TO FIX THE CONTROL PANEL |
| 32     | 160270        |     | COVER                            |
| 33     | 163221        |     | WORK PLANE GRATE                 |
| 34     | 160431        |     | COUNTER DOOR                     |
| 35     | 160432        |     | DOOR                             |
| 36     | 160741        |     | RIGHT SIDE                       |
| 37     | 160740        |     | LEFT SIDE                        |
| 38     | 163177        |     | CONTROL PANEL                    |
| 39     | 163114+163079 | (R) | WATER TAP KNOB+RING              |
| 39     | 163114+163085 | (R) | WATER TAP KNOB+RING              |
| 40     | 164561        |     | BOWL                             |

(R) = - Recommended spare parts

| Key N° | Part N°             | Description             |
|--------|---------------------|-------------------------|
| 41     | 160676              | COVER HANDLE            |
| 42     | 160927              | NIPLES                  |
| 43     | RTCU700324          | FOOT                    |
| 44     | 160983              | EXTERNAL FACE           |
| 45     | 160949              | BOTTOM                  |
| 46     | PACP800010          | PIPE FLEXIBLE           |
| 47     | VEDI MANUALE UGELLI |                         |
| 48     | RTCP800165          | WIRING HARNESS          |
| 49     | RTCP900063          | MANOMETER               |
| 50     | RTBF700038          | (R) LIGHTING CABLE      |
| 51     | RTCP800131          | PROLONGE THERMOCOUPLE   |
| 52     | 160932              | COMPLETE HINGE          |
| 53     | 160436              | BACK CROSS BAR          |
| 54     | 160925              | COVER                   |
| 55     | RTCU900103          | NIPLES 3/8"             |
| 56     | RTCU900012          | DOUBLE CONE D.10        |
| 57     | RTCU900013          | NUT D.10                |
| 58     | GACP900023          | WATER CONNECTION        |
| 59     | 163027              | COLD WATER FEEDING PIPE |
| 60     | 165636              | FEEDING PIPE            |
| 61     | 160940              | WATER FEEDING PIPE      |
| 62     | 163026              | HOT WATER FEEDING PIPE  |
| 63     | RTCU700629          | THREADED BUSH 3/8"      |
| 64     | 160941              | WATER DISCHARGE PIPE    |
| 65     | 160890              | FRONT CROSSBAR          |
| 66     | 160929              | REAR WALL               |
| 67     | 160950              | LOWER PLANE             |
| 68     | 160928              | FLUE FRONT WALL         |
| 69     | 160457              | BRACKET TO FIX BURNER   |
| 70     | 160458              | BURNER PROTECTION       |
| 71     | 163603              | PLUG                    |
| 72     | 160946              | INJECTOR SUPPORT        |

(R) = - Recommended spare parts