





Gas Top Bratt Pan

BCGABP



Spare Parts



HOBART

BCGABP

TAV. 971

Key N°	Part N°		Description
1	RTBF800113	(R)	MICROSWITCH
2	RTFOC00095	(R)	VALVE
3	RTBF800129	(R)	LIGHTING
4	RTBF900039		BOWL FEEDING TAP
5	166220		BURNER
6	RTCP800012		INJECTOR SUPPORT
7	RTCP800033	(R)	ROUND SPARK
8	RTCP800034	(R)	PILOT
9	RTCP800038	(R)	RACCORD THERMOCOUPLE
10	RTCU700652	(R)	THERMOCOUPLE
11	RTCU700085	(R)	THERMOSTAT
12	RTCU700212	(R)	COMMUTATOR
13	RTCU900215		FITTING FOR PILOT SPARK PLUG
14	RTCU900217		BICONE AND NUT Ø 6
15	164572		CHIMMEY GRILL
16	161227+163077	(R)	THERMOSTAT KNOB
17	166216		TANK
17I	166215		COMPOUND TANK
18	161227+163075	(R)	COMMUTATOR KNOB
19	RTBF800123		PUSH BUTTON
20	RTBF800076	(R)	LIMIT THERMOSTAT
21	160506	(R)	ORANGE WARNING LIGHT
22	160505	(R)	GREEN WARNING LIGHT
23	RTBF800015		NUT D.14
24	RTBF800137		DOUBLE CONE D.14
25	RTCU700324		FOOT
26	PACU701022		BRACKET FOR PILOT
27	166120		COMPLETE HINGE
28	RTBF800103		SPRING FOR COVER INGE
29	RTBF900045		TERMINAL BOARD
30	165400		WATER FEEDING PIPE
31	163807		FITTING DEVICE PLUG
32	163208		CONTROL PANEL
33	160667		COLLECTOR
34	160631		NUT SCREW
35	165289		SCREW
36	163203		CENTRAL CONTROL PANEL
37	163188		LEFT CONTROL PANEL
38	160600		LEFT SIDE
39	160601		RIGHT SIDE
40	160516		BALL BEARING SUPPORT

(R) = - Recommended spare parts

Key N°	Part N°	Description
41	160593	COVER
42	160626	BRACKET
43	160660	LEFT SIDE
44	160661	RIGHT SIDE
45	163860	PLANE
46	163799	BALL BEARING
47	165291	REDUCTION UNIT
48	163801	SEEGER Ø 30
49	163802	SEEGER Ø 62
50	166243	BURNER PIPE
51	163804	PILOT PIPE
52	163805	FITTING
53	165292	MOTOR
54	163603	PLUG
55	164524	O-RING
56	166297	BACK PANEL
57	RTCU800349	BURNER AIR SHUTTER
58	RTCU700504	SUPPORT
59	166229	EXTERNAL FACE
60	165311	CHIMMEY GRILL
61	166235	FLUE FRONT WALL
62	166232	REAR WALL
63	RTBF700038	(R) LIGHTING CABLE
64	160028	BRACKET TO FIX THE CONTROL PANEL
65	160612	BRACKET
66	166342	SPRING
67	165906	SCREW
68	RTBF700021	CHOCK
69	165888	ELBOW 1/2"
70	MPGUFE0020	CASE
71	RTCU900415	FEEDING CABLE
72	163806	FITTING DEVICE PLUG
73	166244	FEEDING PIPE
74	160629	FRONT CROSSBAR
75	160253	SUPPORT
76	160259	PIN
77	RTBF800125	PUSH BUTTON CONTACT

(R) = - Recommended spare parts