





Gas Bratt Pans **BMGMBP**



Spare Parts





BMGMBP

TAV. 929


Key N°	Part N°		Description
1	RTBF800113	(R)	Microswitch
2	RTFOC00095	(R)	Valve
3	RTBF800129	(R)	Lighting
4	RTBF900039		Bowl feeding tap
5	RTBF900098		Burner
6	RTCP800012		Injector support
7	RTCP800033	(R)	Round spark
8	RTCP800034		Pilot
9	RTCP800038	(R)	Raccord thermocouple
10	RTCU700652	(R)	Thermocouple
11	RTCU700085	(R)	Thermostat
12	RTCU700212		Commutator
13	RTCU900215		Fitting for pilot spark plug
14	RTCU900217		Bicone and nut Ø 6
15	163221		Chimmey grill 90cm
15a	164572		Chimmey grill 22,5cm
16	163061		Thermostat knob
17	160578		Tank
17l	160576		Compound tank
18	163072		Commutator knob
19	162816		Handw heel
20	RTBF800076	(R)	Limit thermostat
21	160506	(R)	Orange warning light
22	160505	(R)	Green warning light
23	RTBF800015		Nut D. 14
24	RTBF800137		Double cone D. 14
25	RTCU700324		Foot
26	PACU701022		Bracket for pilot
27	RTBF800080		Complete hinge handle & spacers
28	RTBF800103		Spring for cover inge
29	RTBF800149		Terminal board
30	160921		Hinge left terminal
31	160920		Right terminal hinge
32	163185		Control panel
33	160667		Collector
34	160631		Nut screw

(R) = - Recommended spare parts



Key N°	Part N°	Description
35	160635	Screw
36	163203	Central control panel
37	163188	Left control panel
38	160600	Left side
39	160601	Right side
40	160516	Ball bearing support
41	160593	Cover
42	160626	Bracket
43	160660	Left side
44	160793	Right side
45	163860	Plane
46	163799	Ball bearing
47	163800	Spring
48	163801	Seeger Ø 30
49	163802	Seeger Ø 62
50	163803	Burner pipe
51	163804	Pilot pipe
52	163805	Fitting
53	163808	Spring lock
54	163603	Plug
55	164524	OR
56	164573	Back panel
57	RTBF900045	Burner air shutter
58	RTC700504	Support
59	160611	External face

(R) = - Recommended spare parts





As continued product improvement is a policy of HOBART, specifications are subject to change with-out notice.