



HOBART

**SPARE PARTS CATALOGUE
ERSATZTEILKATALOG
CATALOGUE PIECES DETACHEES
CATALOGO PARTI RICAMBIO
CATALOGO DE PIEZAS DE RECAMBIO
CATALOGO PEÇAS DE REPOSIÇÃO**


Ecomax 500


2003












OPTIONAL*









OPTIONAL*












B. 237

13 01 09 (230V- 50Hz)

**T. 173**

7a

13 01 26 (230V- 50Hz)



T. 175