





Oven Range BMG2BSTO



Spare Parts





BMG2BST0

TAV. 971

Key N°	Part N°		Description
1	RTCP800034	(R)	Pilot
2	RTCU900474	(R)	Thermocouple cm. 75
3	RTCP800038		Nut for thermoelement
4	RTCU900215		Fitting for pilot spark plug
5	RTCP800033	(R)	Round spark
6	RTCU800182		Cap D. 6
7	RTCU800183		Bicone D. 6
8	VEDI MAN.		
9	RTCU900011	(R)	Safety valve knob
10	RTCU900018		Bicone D. 6
11	RTCU900019		Cap D. 6
12	RTCU900013		Cap D. 10
13	RTCU900012		Bicone D. 10
14	RTCU900014		Bicone D. 12
15	RTCU900015		Cap D. 12
16	160581		Burner pipe
17	RTCU800303		Burner cap
18	GACU800171		Burner
19	RTCU700020	(R)	Piezo lighting
20	RTCU900384	(R)	Lighting cable
21	163221		Grate
21a	163222		Grate
22	RIC0002358		Central burner
23	160325		Cooking plane
24	163292		Gasket
25	163902		Work plane
26	162706		Inox back panel
27	162676		Side panel right
28	162267		Foot
29	162696		Burner
30	RTBF900054		Spy - hole
31	163067		Safety valve knob
32	RTBF800308	(R)	Lighting cable
33	160270		Handle
34	163205		Control panel
35	RTCU900016		Bicone D. 10
36	163842		Oil collecting drawer
37	RTCU900017		Cap D. 10
38	160641		Insulating panel
39	160642		Insulating panel
40	162677		Left side

(R) = - Recommended spare parts

Key N°	Part N°	Description
41	163772	Collector
42	160640	Insulating panel
43	RTCU900005	Lock nut
44	RTCU800195	Bicone D. 12
45	RTCU800180	Injector support
46	RTCU800181	Cap D. 12
47	RTCU900030	Removal hook
48	VEDI MAN.	
49	162717	Burner air shutter
50	162698	Feeding pipe for burner
51	162699	Pilot pipe
52	RTCU800011	(R) Gas thermostat
53	162697	Injecteur support
54	162458	Handle
55	162678	Oven door
56	162679	Oven counter door
57	163885	Gasket
58	163886	Gasket
59	163888	Gasket
60	163889	Gasket
61	162701	Cover
62	162955	Oven panel
63	RTCU700341	Oven grate
64	162644	Oven lateral panel
65	RTCU900004	Hinge support
66	RTCU900396	Oven door right hinge
67	RTCU900397	Oven door left hinge
68	RTCU700397	Insulating panel
69	163224	Control panel
70	163069	Knob
71	162954	Work plate grate
72	160580	Pilot pipe
73	163123	Oil collecting drawer external panel
74	160141	Front burner distrib. Pipe 3,5 Kw
75	160144	Back burner distrib. Pipe 6 Kw
76	160324	Injector support
77	160344	(R) Tap
78	160465	Front burner pilot pipe
79	160466	Back burner pilot pipe
80	162457	Handle

(R) = - Recommended spare parts

Key N°	Part N°	Description
81	162196	Right door
82	162197	Counter door
83	162198	Left door hinge
84	162199	Right door hinge
85	163603	Plug
86	VEDI MAN.	
87	RTCU700028	Reduction grate
88	RTCU700373	(R) Thermocouple 30
89	RTCU700374	(R) Thermocouple 60
90	RTCU700375	Burner cap 3,5KW
91	RTCU700376	Burner cap 6KW
92	RTCU700748	Burner 3,5 kW
93	RTCU700391	Nut for thermocouple
94	RTCU700399	Gasket
95	RTCU700400	Gasket
96	RTCU700407	Plate
97	RTCU700474	Insulating panel
98	RTCU700749	Burner 6 kW

(R) = - Recommended spare parts





As continued product improvement is a policy of HOBART, specifications are subject to change with-out notice.