






**CATALOGO RICAMBI
SPARE PARTS
PIECES DETACHEES
ERSATZTEILE
LISTA DE RECAMBIOS**









**Lavastoviglie
Dishwashers
Lavevaisselle
Geschirrspüler
Lavavajillas**

**C 68 E - C 68 D E
SP 68 E - SP 68 D E**












Fig. 10










Fig. 10















36943

