





| POS. | CODE      | PIECES | DESCRIPTION                 |
|------|-----------|--------|-----------------------------|
| 1    | R18202060 | 1      | DOOR                        |
| 2    | R18202010 | 1      | INNER DOOR PANEL            |
| 3    | R71201500 | 1      | INNER DOOR GLASS            |
| 4    | R58001760 | 2      | INNER GLASS SOLID HINGE     |
| 5    | R58001770 | 2      | INNER GLASS HINGE PIN       |
| 6    | R58001780 | 2      | INNER GLASS CATCH KIT       |
| 7    | R11401340 | 2      | TOP "C" PROFILE             |
| 8    | R18203910 | 1      | LOWER SUPPORT GLASS         |
| 9    | R18203920 | 1      | TOP SUPPORT GLASS           |
| 10   | R18404500 | 1      | LOWER DOOR HINGE            |
| 11   | R58002520 | 1      | LOWER HINGE PIN             |
| 12   | R11200560 | 1      | UPPER DOOR HINGE            |
| 13   | R58002150 | 1      | HINGE PIN                   |
| 14   | R58004050 | 2      | NUT FOR UPPER DOOR HINGE    |
| 15   | R10401710 | 1      | WASHER FOR UPPER DOOR HINGE |
| 16   | R70050100 | 6      | GLASS SILICON SPACERS       |
| 17   | R70044650 | 1      | GLASS GASKET                |
| 18   | R66110320 | 1      | DOOR LAMPS CABLE SET        |
| 19   | R11401440 | 1      | LAMP COVER                  |
| 20   | R71500150 | 1      | GLASS LAMP                  |
| 21   | R70044200 | 1      | LAMP GASKET                 |


| POS. | CODE      | PIECES | DESCRIPTION                         |
|------|-----------|--------|-------------------------------------|
| 22   | R11401450 | 1      | GLASS HOLDER LAMP FLANGE            |
| 23   | R65270020 | 1      | LIGHT 20W 12V G4                    |
| 24   | R65270450 | 1      | LIGHT SOCKET                        |
| 25   | R65260750 | 1      | LAMPS CONTACT BLOCK                 |
| 26   | R66110300 | 1      | LAMPS CONTACT CABLE SET             |
| 27   | R69015000 | 1      | DOOR HANDLE ASSEMBLY                |
| 28   | R09200230 | 1      | DOOR HANDLE                         |
| 29   | R10100110 | 1      | PRONG FLANGE                        |
| 30   | R58003240 | 1      | DOOR HANDLE BUTTON ROD              |
| 31   | R58004270 | 1      | DOOR HANDLE SPACER                  |
| 32   | R58004830 | 1      | RING NUT M18x1                      |
| 33   | R58005050 | 1      | DOOR HANDLE PRONG                   |
| 34   | R58005340 | 1      | DOOR HANDLE LOWER INSULATION WASHER |
| 35   | R58005350 | 1      | DOOR HANDLE UPPER INSULATION WASHER |
| 36   | R61620012 | 1      | DOOR HANDLE CATCH SPRING            |
| 37   | R61620041 | 1      | DOOR HANDLE BUTTON SPRING           |
| 38   | R69031190 | 1      | DOOR HANDLE PUSH BUTTON             |
| 39   | R58002160 | 1      | DOOR HANDLE PRONG PIN               |
| 40   | R18202020 | 1      | DOOR HANDLE PRONG COUPLER           |

[illegible]

\*COMPONENT SUBMITTED TO CHANGEMENTS CAUSED BY TENSION DIFFERENT FROM THE STANDARD (3N AC400V 50HZ)

[illegible]

\*COMPONENT SUBMITTED TO CHANGEMENTS CAUSED BY TENSION DIFFERENT FROM THE STANDARD (3N AC400V 50HZ)

[illegible][illegible]