








POS.	CODE	PIECES	DESCRIPTION
1	R18100660	1	DOOR ASSEMBLY
2	R18203440	1	CONTROL PANEL
3	R11201970	1	SPRITZER EXTENSION
4	R18200070	1	SPRITZER UNION
5	R18210650	1	COOKING CABINET ASSEMBLY+LEFT SIDE PANEL
6	R18421260	1	FAN GUARD PANEL ASSEMBLY
7	R18421060	1	RIGHT SIDE PANEL
8	R18421080	1	REAR PANEL
9	R18420430	1	COVER PANEL
10	R58006400	4	FAN GUARD FASTENING SCREW
11	R70044850	1	FRONT GASKET
12	R18200160	1	RIGHT REMOVABLE RACK 6 LIV.
13	R18200170	1	LEFT REMOVABLE RACK 6 LIV.
14	R18200200	1	RIGHT REMOVABLE RACK 7 LIV.
15	R18200210	1	LEFT REMOVABLE RACK 7 LIV.

POS.	CODE	PIECES	DESCRIPTION







POS.	CODE	PIECES	DESCRIPTION
1	R18203290	1	DOOR
2	R18420760	1	RIGHT DOOR POST
3	R18420770	1	LEFT DOOR POST
4	R69010220	1	DOORHANDLE
5	R69010630	1	DOORHANDLE COVER
6	R58001760	2	INNER GLASS SOLID HINGE
7	R58001770	2	INNER GLASS HINGE PIN
8	R66110320	1	DOOR LAMPS CABLE SET
9	R71201690	1	OUTER DOOR GLASS
10	R58001780	2	INNER GLASS CATCH KIT
11	R11401350	2	OUTER DOOR GLASS FLANGE
12	R18404500	1	LOWER DOOR HINGE
13	R58002520	1	LOWER HINGE PIN
14	R11401410	1	UPPER DOOR HINGE
15	R58002150	1	UPPER HINGE PIN
16	R58004050	2	NUT FOR UPPER DOOR HINGE
17	R70050100	6	GLASS SILICON SPACERS
18	R11401440	1	LAMP COVER
19	R71500150	1	GLASS LAMP

[illegible]

[illegible]

*COMPONENT SUBMITTED TO CHANGEMENTS CAUSED BY TENSION
DIFFERENT FROM THE STANDARD (AC 230V 50HZ)

[illegible]



POS.	CODE	PIECES	DESCRIPTION
1	R65070360	1	CABINET THERMOSTAT 0°/300°C
2	R65080010	1	MAIN SELECTOR SWITCH
3	R65090020	1	TIMER
4	R65260600	1	SWITCH
5	R65260420	1	HUMIDIFIER PUSH BUTTON
6	R65080150	1	2 POSITIONS SELECTOR SWITCH
7	R65270150	2	ORANGE INDICATING LIGHT
8	R65270160	1	GREEN INDICATING LIGHT
9	-	1	PLATE
10	R69030170	3	KNOB
11	R70044260	1	CONTROL PANEL GASKET

POS.	CODE	PIECES	DESCRIPTION