







POS.	CODE	PIECES	DESCRIPTION
1	R18100320	1	DOOR ASSEMBLY
2	R18203350	1	CONTROL PANEL
3	R18200540	1	SPRITZER EXTENSION
4	R18201430	1	SPRITZER UNION
5	R18210490	1	COOKING CABINET ASSEMBLY
6	R65270510	1	LAMP COVER
7	R18402080	1	FAN GUARD PANEL ASSEMBLY
8	R18402170	1	RIGHT SIDE PANEL
9	R18402160	1	REAR PANEL
10	R18420510	1	COVER PANEL
11	R58006400	2	FAN GUARD FASTENING SCREW
12	R70044340	1	FRONT GASKET
13	R18400500	2	REMOVABLE RACK

POS.	CODE	PIECES	DESCRIPTION





POS.	CODE	PIECES	DESCRIPTION
1	R18203060	1	DOOR
2	R18417920	1	RIGHT DOOR POST
3	R18417930	1	LEFT DOOR POST
4	R69010210	1	DOORHANDLE
5	R69010630	1	DOORHANDLE COVER
6	R58001760	2	INNER GLASS SOLID HINGE
7	R58001770	2	INNER GLASS HINGE PIN
8	R71201570	1	OUTER DOOR GLASS
9	R58001780	2	INNER GLASS CATCH KIT
10	R11401350	2	OUTER DOOR GLASS FLANGE
11	R18421580	1	LOWER DOOR HINGE
12	R58002520	1	LOWER HINGE PIN
13	R18421570	1	UPPER DOOR HINGE
14	R58002150	1	UPPER HINGE PIN
15	R58004050	2	NUT FOR UPPER DOOR HINGE
16	R70050100	6	GLASS SILICON SPACERS
17	R69010260	1	DOOR LATCH 1 STEP
18	R61620132	1	PRONG FLANGE

POS.	CODE	PIECES	DESCRIPTION

[illegible]

tav. C



POS.	CODE	PIECES	DESCRIPTION
1	R65070360	1	CABINET THERMOSTAT 0°/300°C
2	R65080010	1	MAIN SELECTOR SWITCH
3	R65090020	1	TIMER
4	R65080250	1	ENERGY REGULATOR
5	R65260420	1	HUMIDIFIER PUSH BUTTON
6	R65260620	1	RESTORATION PUSH BUTTON
7	R65270300	3	ORANGE INDICATING LIGHT
8	R65270320	1	GREEN INDICATING LIGHT
9	R65270170	1	RED INDICATING LIGHT
10	-	1	PLATE
11	R69030130	4	KNOB
12	R70044250	1	CONTROL PANEL GASKET

POS.	CODE	PIECES	DESCRIPTION