










POS.	CODE	PIECES	DESCRIPTION
1	R18100470	1	DOOR ASSEMBLY
2	R18203450	1	CONTROL PANEL
3	R11201980	1	SPRITZER EXTENSION
4	R11202270	1	SPRITZER UNION
5	R18210340	1	COOKING CABINET ASSEMBLY
6	R18421240	1	FAN GUARD PANEL ASSEMBLY
7	R18420990	1	RIGHT SIDE PANEL
8	R18421020	1	REAR PANEL
9	R18420450	1	COVER PANEL
10	R58006400	4	FAN GUARD FASTENING SCREW
11	R70044830	1	FRONT GASKET
12	R18421390	1	REMOVABLE RACK DX
13	R18421400	1	REMOVABLE RACK SX

POS.	CODE	PIECES	DESCRIPTION

[illegible]

[illegible]

*COMPONENT SUBMITTED TO CHANGEMENTS CAUSED BY TENSION
DIFFERENT FROM THE STANDARD (AC 230V 50HZ)



POS.	CODE	PIECES	DESCRIPTION
1	R65070360	1	CABINET THERMOSTAT 0°/300°C
2	R65080010	1	MAIN SELECTOR SWITCH
3	R65090020	1	TIMER
4	R65080250	1	ENERGY REGULATOR
5	R65260420	1	HUMIDIFIER PUSH BUTTON
6	R65260620	1	RESTORATION PUSH BUTTON
7	R65270150	3	ORANGE INDICATING LIGHT
8	R65270160	1	GREEN INDICATING LIGHT
9	R65270170	1	RED INDICATING LIGHT
10	-	1	PLATE
11	R69030130	2	KNOB
12	R70044260	1	CONTROL PANEL GASKET

POS.	CODE	PIECES	DESCRIPTION