





Lavastoviglie
Lave-vaisselle
Dishwasher
Geschirrspüler


050F


**PARTI DI RICAMBIO
PIECES DETACHEES
SPARE PARTS
ERSATZTEILE**


Ed. 9/93











0400220
0400206
0400041

0400701
0800400

0401004

0400300
0400700
0400002

0400217
0800046
0499999

