



Dishwashers

Ed.
01/2016

Rev. A


from
01/2008


GS350


SPARE PARTS

DSP1

CE







0405063

0500103

0301910

KIT0001
(0301000+0301050+0301061)

KIT0004
(0301050+0301062+0301100)

0800665

0500353

0800652

0800404

0800666

0800652

0800063

0800066

0800163

0800169

0800099

0300005

0300829

0300193

0301910

0300900

0500006

0300026
(60-30)

0300138

0800142

0200515

0500006

0200147

0200295

0800652

0200196

0201455

