





CUCINE TUTTAPIASTRA A GAS

Serie 900

TIPO: 94/04 TCTG, 94/04 TCTGSS, 96/04 TCTGDX, 96/04 TCTGSX, 98/04 TCTG,
94/04 CTGG, 94/04 CTGGSS, 94/04 CTGE, 94/04 CTG, 94/04 CTGSS, 96/04 CTGDX,
96/04 CTGSX, 96/04 CTGGDX, 96/04 CTGGSX, 96/04 CTGEDX, 96/04 CTGESX,
98/04 CTG, 98/04 CTGG, 98/04 CTGE

Parti di ricambio







Parti di ricambio

ID	Tipo	Descrizione	Codici
Module: Parti esterne fuochi e tuttapietra			
10	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E	Piedino	826490142
20	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E	Manopola cucina gas nera	2599200
20	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E	Manopola cucina gas Gas Citta	2599220
30	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E	Griglia smaltata	6A003900
31	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E	Bruciatore (spartifiamma "C")	2510352
32	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E	Bruciatore (bicchiere "C")	2510351
35	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E	Bruciatore (spartifiamma "E") 7kW	2510358
36	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E	Bruciatore (bicchiere "E")	2510357
40	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E	Bacinella	2547750
50	94,96DX,96SX,98	Magnete	826900011
60		Cerniera inferiore destra superiore sinistra porta	826410020
70		Cerniera inferiore sinistra superiore destra porta	826410010
80		Manopola rubinetto	2599200
80		Manopola rubinetto Gas Citta	2599220
90		Piastra	826901070

94T=94/04 TCTG, 94TSS=94/04 TCTGSS, 96TDX=96/04 TCTGDX, 96TSX=96/04 TCTGSX, 98T=98/04 TCTG, 94G=94/04 CTGG, 94GSS=94/04 CTGGSS, 94E=94/04 CTGE, 94=94/04 CTG, 94SS=94/04 CTGSS, 96DX=96/04 CTGDX, 96SX=96/04 CTGSX, 96GDX=96/04 CTGGDX, 96GSX=96/04 CTGGSX, 96EDX=96/04 CTGEDX, 96ESX=96/04 CTGESX, 98=98/04 CTG, 98G=98/04 CTGG, 98E=98/04 CTGE

A=3/N/PE~400/230V 50Hz, H=3/PE~230V 50Hz, P=1/N/PE~220-240V 50Hz




Parti di ricambio

ID	Tipo	Descrizione	Codici
Module: Parti esterne fuochi e tuttapietra 1/2 modulo			
10	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS	Piedino	826490142
20	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS	Manopola cucina gas nera	2599200
20	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E	Manopola cucina gas Gas Citta	2599220
30	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS	Griglia smaltata	6A003900
31	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS	Bruciatore (spartifiamma "C")	2510352
32	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS	Bruciatore (bicchiere "C")	2510351
35	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E	Bruciatore (spartifiamma "E") 7kW	2510358
36	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E	Bruciatore (bicchiere "E")	2510357
40	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS	Bacinella	2547750
80		Manopola rubinetto	2599200
80		Manopola rubinetto Gas Citta	2599220
110	94G,96GDX,96GSX,98G,94SS,94TSS,94GSS	Accensione piezoelettrica	6A041105
120	94G,96GDX,96GSX,98G,94SS,94TSS,94GSS	Rondella	822160540
130	94G,96GDX,96GSX,98G,94SS,94TSS,94GSS	Cappuccio	826630420
870	94SS,94TSS,94GSS	Piastra	2519670

94T=94/04 TCTG, 94TSS=94/04 TCTGSS, 96TDX=96/04 TCTGDX, 96TSX=96/04 TCTGSX, 98T=98/04 TCTG, 94G=94/04 CTGG, 94GSS=94/04 CTGGSS, 94E=94/04 CTGE, 94=94/04 CTG, 94SS=94/04 CTGSS, 96DX=96/04 CTGDX, 96SX=96/04 CTGSX, 96GDX=96/04 CTGGDX, 96GSX=96/04 CTGGSX, 96EDX=96/04 CTGEDX, 96ESX=96/04 CTGESX, 98=98/04 CTG, 98G=98/04 CTGG, 98E=98/04 CTGE

A=3/N/PE~400/230V 50Hz, H=3/PE~230V 50Hz, P=1/N/PE~220-240V 50Hz






Parti di ricambio

ID	Tipo	Descrizione	Codici
Module: Parti esterne forno gas ed elettrico			
100	94G,96GDX,96GSX,98G,94GSS	Manopola nera per forno e frytop gas	2599202
110	94G,96GDX,96GSX,98G,94GSS	Accensione piezoelettrica	6A041105
120	94G,96GDX,96GSX,98G,94GSS	Rondella	822160540
130	94G,96GDX,96GSX,98G,94GSS	Cappuccio	826630420
140	94G,96GDX,96GSX,98G,94E,96EDX,96ESX,98E,94GSS	Portarullini per cerniera	6A035930
150	94G,96GDX,96GSX,98G,94E,96EDX,96ESX,98E,94GSS	Cerniera dx	6A035910
160	94G,96GDX,96GSX,98G,94E,96EDX,96ESX,98E,94GSS	Cerniera sx	6A035920
170	94G,96GDX,96GSX,98G,94E,96EDX,96ESX,98E,94GSS	Suola forno	822420010
180	94G,96GDX,96GSX,98G,94E,96EDX,96ESX,98E,94GSS	Griglia	826330020
21	94G,96GDX,96GSX,98G,94GSS	Guarnizione manopola	2519490
80	94E,96EDX,96ESX,98E	Segnalatori luminosi	6A038506
81	94E,96EDX,96ESX,98E	Gemma bianca	6A039207
190	94E,96EDX,96ESX,98E	Gemma verde	6A038507
200	94E,96EDX,96ESX,98E	Manopola commutatore forno elettrico nera	2599207
210	94E,96EDX,96ESX,98E	Manopola forno elettrico nera	2599208
220	94E,96EDX,96ESX,98E	Resistenza 1500 W	826620041

94T=94/04 TCTG, 94TSS=94/04 TCTGSS, 96TDX=96/04 TCTGDX, 96TSX=96/04 TCTGSX, 98T=98/04 TCTG, 94G=94/04 CTGG, 94GSS=94/04 CTGGSS, 94E=94/04 CTGE, 94=94/04 CTG, 94SS=94/04 CTGSS, 96DX=96/04 CTGDX, 96SX=96/04 CTGSX, 96GDX=96/04 CTGGDX, 96GSX=96/04 CTGGSX, 96EDX=96/04 CTGEDX, 96ESX=96/04 CTGESX, 98=98/04 CTG, 98G=98/04 CTGG, 98E=98/04 CTGE

A=3/N/PE~400/230V 50Hz, H=3/PE~230V 50Hz, P=1/N/PE~220-240V 50Hz






Parti di ricambio

ID	Tipo	Descrizione	Codici
Module: Bruciatori e condutture fuochi aperti			
230	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS	Rubinetto	6A011490
230	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS	Rubinetto Gas Citta	6A011500
240	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS	Pilota	2510359
250	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS	Conduttura	2514608
260	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS	Conduttura	2514602
260	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS	Conduttura Gas Citta	2515152
270	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS	Termocoppia	6A011905
280	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS	Bruciatore (bicchiere "C") 3,5 kW	2510350
290	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS	Tubo portafiamma	2519000
300	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS	Raccordo	6A014708
310	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS	Regolatore d'aria	2519002
320	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS	Bruciatore (bicchiere "E") 7 kW	2510356
330	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS	Conduttura	2514609
390	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS	Vite	2510610
400	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS	Conduttura	2514603
400	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS	Conduttura Gas Citta	2515155

94T=94/04 TCTG, 94TSS=94/04 TCTGSS, 96TDX=96/04 TCTGDX, 96TSX=96/04 TCTGSX, 98T=98/04 TCTG, 94G=94/04 CTGG, 94GSS=94/04 CTGGSS, 94E=94/04 CTGE, 94=94/04 CTG, 94SS=94/04 CTGSS, 96DX=96/04 CTGDX, 96SX=96/04 CTGSX, 96GDX=96/04 CTGGDX, 96GSX=96/04 CTGGSX, 96EDX=96/04 CTGEDX, 96ESX=96/04 CTGESX, 98=98/04 CTG, 98G=98/04 CTGG, 98E=98/04 CTGE

A=3/N/PE~400/230V 50Hz, H=3/PE~230V 50Hz, P=1/N/PE~220-240V 50Hz






ID	Tipo	Descrizione	Codici
Module: Ugelli fuochi aperti			
301	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98 G,98E,94SS,94TSS,94GSS	Vite	2510610
302	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98 G,98E,94SS,94TSS,94GSS	Controdado	6A010820
303	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98 G,98E,94SS,94TSS,94GSS	Kit ugelli IT fuochi aperti brucia- tore "C"	2592800
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98 G,98E,94SS,94TSS,94GSS	Ugello L 90	
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98 G,98E,94SS,94TSS,94GSS	Ugello L 140	
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98 G,98E,94SS,94TSS,94GSS	Ugello 20	
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98 G,98E,94SS,94TSS,94GSS	Ugello 35	
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98 G,98E,94SS,94TSS,94GSS	By pass	
303	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98 G,98E,94SS,94TSS,94GSS	Kit ugelli IT fuochi aperti brucia- tore "E"	2592804
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98 G,98E,94SS,94TSS,94GSS	Ugello L 130	
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98 G,98E,94SS,94TSS,94GSS	Ugello L 185R	
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98 G,98E,94SS,94TSS,94GSS	Ugello 20	
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98 G,98E,94SS,94TSS,94GSS	Ugello 35	
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98 G,98E,94SS,94TSS,94GSS	By pass	
303	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98 G,98E,94SS,94TSS,94GSS	Kit ugelli DE fuochi aperti brucia- tore "C"	2592801
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98 G,98E,94SS,94TSS,94GSS	Ugello L 80	
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98 G,98E,94SS,94TSS,94GSS	Ugello L 140	
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98 G,98E,94SS,94TSS,94GSS	Ugello L 150	
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98 G,98E,94SS,94TSS,94GSS	Ugello 20	
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98 G,98E,94SS,94TSS,94GSS	Ugello 35	
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98 G,98E,94SS,94TSS,94GSS	By pass	

94T=94/04 TCTG, 94TSS=94/04 TCTGSS, 96TDX=96/04 TCTGDX, 96TSX=96/04 TCTGSX, 98T=98/04 TCTG,
94G=94/04 CTGG, 94GSS=94/04 CTGGSS, 94E=94/04 CTGE, 94=94/04 CTG, 94SS=94/04 CTGSS, 96DX=96/04
CTGDX, 96SX=96/04 CTGSX, 96GDX=96/04 CTGGDX, 96GSX=96/04 CTGGSX, 96EDX=96/04 CTGEDX, 96ESX=96/
04 CTGESX, 98=98/04 CTG, 98G=98/04 CTGG, 98E=98/04 CTGE

A=3/N/PE~400/230V 50Hz, H=3/PE~230V 50Hz, P=1/N/PE~220-240V 50Hz






ID	Tipo	Descrizione	Codici
Module: Ugelli fuochi aperti			
303	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS	Kit ugelli DE fuochi aperti bruciatore "E"	2592805
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS	Ugello L 115	
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS	Ugello L 185R	
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS	Ugello L 200R	
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS	Ugello 20	
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS	Ugello 35	
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS	By pass	
303	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS	Kit ugelli H fuochi aperti bruciatore "C"	2592863
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS	Ugello L 90	
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS	Ugello L 130	
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS	Ugello L 150	
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS	Ugello 20	
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS	Ugello 35	
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS	By pass	
303	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS	Kit ugelli H fuochi aperti bruciatore "E"	2592865
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS	Ugello L 130	
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS	Ugello L 175	
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS	Ugello L 200R	
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS	Ugello 20	
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS	Ugello 35	
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS	By pass	

94T=94/04 TCTG, 94TSS=94/04 TCTGSS, 96TDX=96/04 TCTGDX, 96TSX=96/04 TCTGSX, 98T=98/04 TCTG, 94G=94/04 CTGG, 94GSS=94/04 CTGGSS, 94E=94/04 CTGE, 94=94/04 CTG, 94SS=94/04 CTGSS, 96DX=96/04 CTGDX, 96SX=96/04 CTGSX, 96GDX=96/04 CTGGDX, 96GSX=96/04 CTGGSX, 96EDX=96/04 CTGEDX, 96ESX=96/04 CTGESX, 98=98/04 CTG, 98G=98/04 CTGG, 98E=98/04 CTGE

A=3/N/PE~400/230V 50Hz, H=3/PE~230V 50Hz, P=1/N/PE~220-240V 50Hz






Parti di ricambio

ID	Tipo	Descrizione	Codici
Module: Ugelli fuochi aperti			
303	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS	Kit ugelli Gas Citta fuochi aperti bruciatore "C"	2592880
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS	Ugello L 90	
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS	Ugello L 140	
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS	Ugello L 265	
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS	Ugello L 250	
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS	Ugello 70	
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS	Ugello 20	
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS	Ugello 35	
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS	By pass	
303	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS	Kit ugelli Gas Citta fuochi aperti bruciatore "E"	2592882
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS	Ugello L 130	
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS	Ugello L 185R	
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS	Ugello L 390	
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS	Ugello L 370	
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS	Ugello 70	
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS	Ugello 20	
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS	Ugello 35	
-	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS	By pass	
304	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS	Bicono	6A011470
304	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS	Bicono Gas Citta	6A016300
305	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS	Dado	6A011475
305	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS	Dado Gas Citta	6A016200

94T=94/04 TCTG, 94TSS=94/04 TCTGSS, 96TDX=96/04 TCTGDX, 96TSX=96/04 TCTGSX, 98T=98/04 TCTG, 94G=94/04 CTGG, 94GSS=94/04 CTGGSS, 94E=94/04 CTGE, 94=94/04 CTG, 94SS=94/04 CTGSS, 96DX=96/04 CTGDX, 96SX=96/04 CTGSX, 96GDX=96/04 CTGGDX, 96GSX=96/04 CTGGSX, 96EDX=96/04 CTGEDX, 96ESX=96/04 CTGESX, 98=98/04 CTG, 98G=98/04 CTGG, 98E=98/04 CTGE

A=3/N/PE~400/230V 50Hz, H=3/PE~230V 50Hz, P=1/N/PE~220-240V 50Hz







Parti di ricambio

ID	Tipo	Descrizione	Codici
Module: Bruciatori e condutture fuochi aperti			
240	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS	Pilota	2510359
241	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS	Ugello 70	6A013110
241	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS	Ugello 20	6A013101
241	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS	Ugello 35	6A013103
242	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS	Raccordo bicono	6A011608
243	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS	Regolatore d'aria	6A013104
290	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E,94SS,94TSS,94GSS	Tubo portafiamma	2519000

94T=94/04 TCTG, 94TSS=94/04 TCTGSS, 96TDX=96/04 TCTGDX, 96TSX=96/04 TCTGSX, 98T=98/04 TCTG, 94G=94/04 CTGG, 94GSS=94/04 CTGGSS, 94E=94/04 CTGE, 94=94/04 CTG, 94SS=94/04 CTGSS, 96DX=96/04 CTGDX, 96SX=96/04 CTGSX, 96GDX=96/04 CTGGDX, 96GSX=96/04 CTGGSX, 96EDX=96/04 CTGEDX, 96ESX=96/04 CTGESX, 98=98/04 CTG, 98G=98/04 CTGG, 98E=98/04 CTGE

A=3/N/PE~400/230V 50Hz, H=3/PE~230V 50Hz, P=1/N/PE~220-240V 50Hz







Parti di ricambio

ID	Tipo	Descrizione	Codici
Module: Rubinetto			
230	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98 G,98E,94SS,94TSS,94GSS	Rubinetto	6A011490
230	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98 G,98E,94SS,94TSS,94GSS	Rubinetto Gas Citta	6A011500
270	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98 G,98E,94SS,94TSS,94GSS	Termocoppia	6A011905
710	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98 G,98E,94SS,94TSS,94GSS	Dado	6A011485
710	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98 G,98E,94SS,94TSS,94GSS	Dado Gas Citta	6A016200
720	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98 G,98E,94SS,94TSS,94GSS	Bicono	6A011480
720	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98 G,98E,94SS,94TSS,94GSS	Bicono Gas Citta	6A016300
730	94SS,94TSS,94GSS	Rubinetto	6A011490
730	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98 G,98E,94SS,94TSS,94GSS	Rubinetto Gas Citta	6A013600
730	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98 G,98E	Rubinetto Gas Citta	6A011500
740	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98 G,98E,94SS,94TSS,94GSS	Raccordo	6A013401
750	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98 G,98E	Conduttura	2514750
750	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98 G,98E	Conduttura Gas Citta	2515160
750	94SS,94TSS,94GSS	Conduttura	2514755
750	94SS,94TSS,94GSS	Conduttura Gas Citta	2515161
751	94SS,94TSS,94GSS	Dado di fissaggio del bicono	6A016200
751	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98 G,98E	Dado Gas Citta	6A016200
752	94SS,94TSS,94GSS	Bicono	6A016300
752	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98 G,98E	Bicono Gas Citta	6A016300
760	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98 G,98E	Conduttura	2514751
760	94SS,94TSS,94GSS	Conduttura	2514756
770	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98 G,98E,94SS,94TSS,94GSS	Dado	6A016110
780	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98 G,98E,94SS,94TSS,94GSS	Bicono	6A016120
480	96TDX,96TSX,98T,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98 G,98E,94SS,94TSS,94GSS	Termocoppia	6A011904

94T=94/04 TCTG, 94TSS=94/04 TCTGSS, 96TDX=96/04 TCTGDX, 96TSX=96/04 TCTGSX, 98T=98/04 TCTG,
 94G=94/04 CTGG, 94GSS=94/04 CTGGSS, 94E=94/04 CTGE, 94=94/04 CTG, 94SS=94/04 CTGSS, 96DX=96/04
 CTGDX, 96SX=96/04 CTGSX, 96GDX=96/04 CTGGDX, 96GSX=96/04 CTGGSX, 96EDX=96/04 CTGEDX, 96ESX=96/
 04 CTGESX, 98=98/04 CTG, 98G=98/04 CTGG, 98E=98/04 CTGE

A=3/N/PE~400/230V 50Hz, H=3/PE~230V 50Hz, P=1/N/PE~220-240V 50Hz






Parti di ricambio

ID	Tipo	Descrizione	Codici
Module: Componenti forno a gas			
410	94G,96GDX,96GSX,98G,94GSS	Valvola	8219950
420	94G,96GDX,96GSX,98G,94GSS	Tappo	8219951
430	94G,96GDX,96GSX,98G,94GSS	Raccordo	822450170
440	94G,96GDX,96GSX,98G,94GSS	Accensione piezoelettrica	6A041105
450	94G,96GDX,96GSX,98G,94GSS	Cavo d'accensione	2510698
460	94G,96GDX,96GSX,98G,94GSS	Conduttura	2514615
470	94G,96GDX,96GSX,98G,94GSS	Conduttura	823560060
480	94G,96GDX,96GSX,98G,94GSS	Termocoppia	6A011904
490	94G,96GDX,96GSX,98G,94GSS	Conduttura	823560070
500	94G,96GDX,96GSX,98G,94GSS	Squadretta	2547780
510	94G,96GDX,96GSX,98G,94GSS	Raccordo	6A011707
520	94G,96GDX,96GSX,98G,94GSS	Raccordo bicono	6A011608
530	94G,96GDX,96GSX,98G,94GSS	Ugello 19	822140380
530	94G,96GDX,96GSX,98G,94GSS	Ugello 27	6A013107
530	94G,96GDX,96GSX,98G,94GSS	Ugello 36	822140530
530	94G,96GDX,96GSX,98G,94GSS	Ugello 50	6A013108
540	94G,96GDX,96GSX,98G,94GSS	Raccordo	822450040
550	94G,96GDX,96GSX,98G,94GSS	Pilota	826920070
560	94G,96GDX,96GSX,98G,94GSS	Bruciatore	2510697
570	94G,96GDX,96GSX,98G,94GSS	Candela	6A013301
580	94G,96GDX,96GSX,98G,94GSS	Spina elastica	6A011405
590	94G,96GDX,96GSX,98G,94GSS	Flangia	824710060
600	94G,96GDX,96GSX,98G,94GSS	Attacco manopola	822160011
610	94G,96GDX,96GSX,98G,94GSS	Bicono	822450050
620	94G,96GDX,96GSX,98G,94GSS	Raccordo	822450010
630	94G,96GDX,96GSX,98G,94GSS	Dado	822180010
640	94G,96GDX,96GSX,98G,94GSS	Rondella	821110840
710	94G,96GDX,96GSX,98G,94GSS	Kit ugelli IT DE forno	861310090

94T=94/04 TCTG, 94TSS=94/04 TCTGSS, 96TDX=96/04 TCTGDX, 96TSX=96/04 TCTGSX, 98T=98/04 TCTG, 94G=94/04 CTGG, 94GSS=94/04 CTGGSS, 94E=94/04 CTGE, 94=94/04 CTG, 94SS=94/04 CTGSS, 96DX=96/04 CTGDX, 96SX=96/04 CTGSX, 96GDX=96/04 CTGGDX, 96GSX=96/04 CTGGSX, 96EDX=96/04 CTGEDX, 96ESX=96/04 CTGESX, 98=98/04 CTG, 98G=98/04 CTGG, 98E=98/04 CTGE

A=3/N/PE~400/230V 50Hz, H=3/PE~230V 50Hz, P=1/N/PE~220-240V 50Hz






Parti di ricambio

ID	Tipo	Descrizione	Codici
Module: Componenti forno a gas			
-	94G,96GDX,96GSX,98G,94GSS	Ugello BA 130	
-	94G,96GDX,96GSX,98G,94GSS	Ugello BA 145	
-	94G,96GDX,96GSX,98G,94GSS	Ugello BA 245	
-	94G,96GDX,96GSX,98G,94GSS	Ugello BA 225	
-	94G,96GDX,96GSX,98G,94GSS	Ugello 27	
-	94G,96GDX,96GSX,98G,94GSS	Ugello 19	
710	94G,96GDX,96GSX,98G,94GSS	Kit ugelli H forno	2592849
-	94G,96GDX,96GSX,98G,94GSS	Ugello BA 145	
-	94G,96GDX,96GSX,98G,94GSS	Ugello BA 245	
-	94G,96GDX,96GSX,98G,94GSS	Ugello BA 215	
-	94G,96GDX,96GSX,98G,94GSS	Ugello 19	
-	94G,96GDX,96GSX,98G,94GSS	Ugello 27	
-	94G,96GDX,96GSX,98G,94GSS	Ugello 36	
710	94G,96GDX,96GSX,98G,94GSS	Kit ugelli Gas Citta forno a gas	2592884
-	94G,96GDX,96GSX,98G,94GSS	Ugello BA 145	
-	94G,96GDX,96GSX,98G,94GSS	Ugello BA 225	
-	94G,96GDX,96GSX,98G,94GSS	Ugello BA 540	
-	94G,96GDX,96GSX,98G,94GSS	Ugello BA 500	
-	94G,96GDX,96GSX,98G,94GSS	Ugello 19	
-	94G,96GDX,96GSX,98G,94GSS	Ugello 27	
-	94G,96GDX,96GSX,98G,94GSS	Ugello 50	

94T=94/04 TCTG, 94TSS=94/04 TCTGSS, 96TDX=96/04 TCTGDX, 96TSX=96/04 TCTGSX, 98T=98/04 TCTG, 94G=94/04 CTGG, 94GSS=94/04 CTGGSS, 94E=94/04 CTGE, 94=94/04 CTG, 94SS=94/04 CTGSS, 96DX=96/04 CTGDX, 96SX=96/04 CTGSX, 96GDX=96/04 CTGGDX, 96GSX=96/04 CTGGSX, 96EDX=96/04 CTGEDX, 96ESX=96/04 CTGESX, 98=98/04 CTG, 98G=98/04 CTGG, 98E=98/04 CTGE

A=3/N/PE~400/230V 50Hz, H=3/PE~230V 50Hz, P=1/N/PE~220-240V 50Hz








Parti di ricambio

ID	Tipo	Descrizione	Codici
Module: Componenti forno elettrico			
81	94E,96EDX,96ESX,98E	Gemma bianca	6A039207
190	94E,96EDX,96ESX,98E	Gemma verde	6A038507
660	94E,96EDX,96ESX,98E	Commutatore	6A046750
670	94E,96EDX,96ESX,98E	Termostato	826630123
680	94E,96EDX,96ESX,98E	Termostato sicurezza	826630130
690	94E,96EDX,96ESX,98E	Commutatore	6A046001
220	94E,96EDX,96ESX,98E	Resistenza 1500 W	826620041
700	94E,96EDX,96ESX,98E	Morsettiera	6A036206
720	94E,96EDX,96ESX,98E	Minicontattore	6A047031

94T=94/04 TCTG, 94TSS=94/04 TCTGSS, 96TDX=96/04 TCTGDX, 96TSX=96/04 TCTGSX, 98T=98/04 TCTG, 94G=94/04 CTGG, 94GSS=94/04 CTGGSS, 94E=94/04 CTGE, 94=94/04 CTG, 94SS=94/04 CTGSS, 96DX=96/04 CTGDX, 96SX=96/04 CTGSX, 96GDX=96/04 CTGGDX, 96GSX=96/04 CTGGSX, 96EDX=96/04 CTGEDX, 96ESX=96/04 CTGESX, 98=98/04 CTG, 98G=98/04 CTGG, 98E=98/04 CTGE

A=3/N/PE~400/230V 50Hz, H=3/PE~230V 50Hz, P=1/N/PE~220-240V 50Hz




Parti di ricambio

ID	Tipo	Descrizione	Codici
Module: Pilota e bruciatore tuttapiestra			
480		Termocoppia	6A011904
790		Dado	6A017000
800		Bicono	6A016900
810		Ugello 27.2	6A013230
810		Ugello 16.2	6A013240
810		Ugello 38.1.2	2510332
810		Ugello 45.2	2510716
820		Candela di accensione	6A013302
830		Pilota	6A013220
840	94T,96TDX,96TSX,98T,94G,94E,94,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E	Bruciatore tuttapiestra	2510069
850	94T,96TDX,96TSX,98T,94G,94E,94,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E	Controdado	6A010820
860	94T,96TDX,96TSX,98T,94G,94E,94,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E	Kit ugelli IT bruciatore	2592810
-	94T,96TDX,96TSX,98T,94G,94E,94,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E	Ugello L 180	
-	94T,96TDX,96TSX,98T,94G,94E,94,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E	Ugello L 255R	
-	94T,96TDX,96TSX,98T,94G,94E,94,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E	Ugello L 270R	
-	94T,96TDX,96TSX,98T,94G,94E,94,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E	Ugello 16.2	
-	94T,96TDX,96TSX,98T,94G,94E,94,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E	Ugello 27.2	
-	94T,96TDX,96TSX,98T,94G,94E,94,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E	By pass	
860	94T,96TDX,96TSX,98T,94G,94E,94,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E	Kit ugelli DE bruciatore	2592811
-	94T,96TDX,96TSX,98T,94G,94E,94,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E	Ugello L 155R	
-	94T,96TDX,96TSX,98T,94G,94E,94,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E	Ugello L 255R	
-	94T,96TDX,96TSX,98T,94G,94E,94,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E	Ugello L 280R	
-	94T,96TDX,96TSX,98T,94G,94E,94,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E	Ugello 16.2	
-	94T,96TDX,96TSX,98T,94G,94E,94,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E	Ugello 27.2	
-	94T,96TDX,96TSX,98T,94G,94E,94,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E	By pass	

94T=94/04 TCTG, 94TSS=94/04 TCTGSS, 96TDX=96/04 TCTGDX, 96TSX=96/04 TCTGSX, 98T=98/04 TCTG, 94G=94/04 CTGG, 94GSS=94/04 CTGGSS, 94E=94/04 CTGE, 94=94/04 CTG, 94SS=94/04 CTGSS, 96DX=96/04 CTGDX, 96SX=96/04 CTGSX, 96GDX=96/04 CTGGDX, 96GSX=96/04 CTGGSX, 96EDX=96/04 CTGEDX, 96ESX=96/04 CTGESX, 98=98/04 CTG, 98G=98/04 CTGG, 98E=98/04 CTGE

A=3/N/PE~400/230V 50Hz, H=3/PE~230V 50Hz, P=1/N/PE~220-240V 50Hz







Parti di ricambio

ID	Tipo	Descrizione	Codici
Module: Pilota e bruciatore tuttapietra			
860	94T,96TDX,96TSX,98T,94G,94E,94,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E	Kit ugelli H bruciatore	2592857
-	94T,96TDX,96TSX,98T,94G,94E,94,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E	Ugello L 235R	
-	94T,96TDX,96TSX,98T,94G,94E,94,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E	Ugello L 180	
-	94T,96TDX,96TSX,98T,94G,94E,94,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E	Ugello L 270R	
-	94T,96TDX,96TSX,98T,94G,94E,94,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E	Ugello 16.2	
-	94T,96TDX,96TSX,98T,94G,94E,94,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E	Ugello 27.2	
-	94T,96TDX,96TSX,98T,94G,94E,94,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E	Ugello 38.1.2	
-	94T,96TDX,96TSX,98T,94G,94E,94,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E	By pass	
860	94T,96TDX,96TSX,98T,94G,94E,94,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E	Kit ugelli Gas Citta bruciatore	2592885
-	94T,96TDX,96TSX,98T,94G,94E,94,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E	Ugello L 180	
-	94T,96TDX,96TSX,98T,94G,94E,94,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E	Ugello L 255R	
-	94T,96TDX,96TSX,98T,94G,94E,94,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E	Ugello L 560	
-	94T,96TDX,96TSX,98T,94G,94E,94,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E	Ugello 16.2	
-	94T,96TDX,96TSX,98T,94G,94E,94,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E	Ugello 27.2	
-	94T,96TDX,96TSX,98T,94G,94E,94,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E	Ugello 45.2	
-	94T,96TDX,96TSX,98T,94G,94E,94,96DX,96SX,96GDX,96GSX,96EDX,96ESX,98,98G,98E	By pass	

94T=94/04 TCTG, 94TSS=94/04 TCTGSS, 96TDX=96/04 TCTGDX, 96TSX=96/04 TCTGSX, 98T=98/04 TCTG, 94G=94/04 CTGG, 94GSS=94/04 CTGGSS, 94E=94/04 CTGE, 94=94/04 CTG, 94SS=94/04 CTGSS, 96DX=96/04 CTGDX, 96SX=96/04 CTGSX, 96GDX=96/04 CTGGDX, 96GSX=96/04 CTGGSX, 96EDX=96/04 CTGEDX, 96ESX=96/04 CTGESX, 98=98/04 CTG, 98G=98/04 CTGG, 98E=98/04 CTGE

A=3/N/PE~400/230V 50Hz, H=3/PE~230V 50Hz, P=1/N/PE~220-240V 50Hz





Parti di ricambio

ID	Tipo	Descrizione	Codici
Module:Pilota e bruciatore tuttapiestra 1/2 modulo			
480		Termocoppia	6A011904
790		Dado	6A017000
800		Bicono	6A016900
810		Ugello 27.2	6A013230
810		Ugello 16.2	6A013240
810		Ugello 38.1.2	2510332
810		Ugello 45.2	2510716
820		Candela di accensione	6A013302
830		Pilota	6A013220
880	94SS,94TSS,94GSS	Bruciatore tuttapiestra	2519420
850	94SS,94TSS,94GSS	Controdado	6A010820
860	94SS,94TSS,94GSS	Kit ugelli IT bruciatore	
-	94SS,94TSS,94GSS	Ugello L 135	
-	94SS,94TSS,94GSS	Ugello L 200	
-	94SS,94TSS,94GSS	Ugello L 210	
-	94SS,94TSS,94GSS	Ugello 16.2	
-	94SS,94TSS,94GSS	Ugello 27.2	
-	94SS,94TSS,94GSS	By pass	
860	94SS,94TSS,94GSS	Kit ugelli DE bruciatore	
-	94SS,94TSS,94GSS	Ugello L 115	
-	94SS,94TSS,94GSS	Ugello L 200	
-	94SS,94TSS,94GSS	Ugello L 220	
-	94SS,94TSS,94GSS	Ugello 16.2	
-	94SS,94TSS,94GSS	Ugello 27.2	
-	94SS,94TSS,94GSS	By pass	
860	94SS,94TSS,94GSS	Kit ugelli H bruciatore	2592857
-	94SS,94TSS,94GSS	Ugello L 135	
-	94SS,94TSS,94GSS	Ugello L 190	
-	94SS,94TSS,94GSS	Ugello L 215	
-	94SS,94TSS,94GSS	Ugello 16.2	
-	94SS,94TSS,94GSS	Ugello 27.2	
-	94SS,94TSS,94GSS	Ugello 38.1.2	
-	94SS,94TSS,94GSS	By pass	
860	94SS,94TSS,94GSS	Kit ugelli Gas Citta bruciatore	2592888
-	94SS,94TSS,94GSS	Ugello L 135	
-	94SS,94TSS,94GSS	Ugello L 200	
-	94SS,94TSS,94GSS	By pass	
-	94SS,94TSS,94GSS	Ugello 16.2	
-	94SS,94TSS,94GSS	Ugello 27.2	
-	94SS,94TSS,94GSS	Ugello 45.2	
-	94SS,94TSS,94GSS	Ugello L 380	
-	94SS,94TSS,94GSS	Ugello L 355	

94T=94/04 TCTG, 94TSS=94/04 TCTGSS, 96TDX=96/04 TCTGDX, 96TSX=96/04 TCTGSX, 98T=98/04 TCTG, 94G=94/04 CTGG, 94GSS=94/04 CTGGSS, 94E=94/04 CTGE, 94=94/04 CTG, 94SS=94/04 CTGSS, 96DX=96/04 CTGDX, 96SX=96/04 CTGSX, 96GDX=96/04 CTGGDX, 96GSX=96/04 CTGGSX, 96EDX=96/04 CTGEDX, 96ESX=96/04 CTGESX, 98=98/04 CTG, 98G=98/04 CTGG, 98E=98/04 CTGE

A=3/N/PE~400/230V 50Hz, H=3/PE~230V 50Hz, P=1/N/PE~220-240V 50Hz

