




PFL105E..



PF70E..





CODICI RICAMBIO PER FINITO / SPARE PARTS FOR THE FINISHED PRODUCT
Aggiornato al/Updated to 27/11/17

Artic./Item	Descrizione/Description		Modello/Model
126008	CUCINA ELETTRICA 4 PIASTRE CON FORNO ELETTRICO VENTILATO 4 HOT PLATES ELECTRIC RANGE WITH FAN ASSISTED ELECTRIC OVEN		PF70E/0
Cons./Recom.	Pos./Posit.	Ricambio/Replacement	Prezzo/Price List
	00566000	RC00566000 LAMPADA 25W	LAMP 13,24
	00568000	RC00568000 RESISTENZA 2.5KW PER FORNO	OVEN HEATING ELEMENT 47,88
	00939000	RC00939000 CERNIERA DX PORTA FORNO 60	RIGHT HINGE FOR OVEN "60" 27,60
	00940000	RC00940000 CERNIERA SX PORTA FORNO 60	LEFT HINGE FOR OVEN "60" 27,60
	02247000	RC02247000 PORTA FORNO COMPLETA SNACK C/MANIGLIA	234,00
	01	RC00428000 ASSIEME CAMINO 700	FLUE ASSEMBLY 700 85,06
	04	RC01251000 FIANCO DX SNACK	RIGHT SIDE SNACK 32,77
	05	RC00791000 FONDO ELETTRICO 700	BASE EL. 700 33,43
	06	RC00304000 MORSETTO EQUIPOTENZIALE COMPLETO	EQUIPOTENTIAL CONNECTING BLOCK 6,62
	08	RC00241000 PRESSACAVO PG16 CON DADO	CABLE GLAND AND NUT 7,18
	09	RC00194000 MORSETTIERA FV 122 B	CONNECTING BLOCK 9,16
*	10	RC00291000 COMMUTATORE	SWITCH 19,97
*	11	RC01782000 LAMPADA SEGN.NEON FASTON VERDE 230V	GREEN NEON LAMP 230V 6,09
*	12	RC01783000 PORTALAMPADA TRASPARENTE D10	TRANSPARENT LAMP HOLDER D10 5,30
	13	RC02029000 MANOPOLA PCE NERA	BLACK KNOB 9,76
	13	RC02071000 MANOPOLA PCE GRIGIA	GREY KNOB 9,05
	15	RC00655000 CRUSCOTTO PC70E	CONTROL PANEL PC70E 71,28
	16	RC01252000 FIANCO SX SNACK	LEFT SIDE SNACK 32,77
	17	RC00614000 RIPIANO PC70E	SHELF PC70E 211,62
	18	RC00290000 PIASTRA ELETTRICA	HOT PLATE 46,78
*	22	RC00037000 COMMUTATORE MONOFASE	SWITCH 19,64
	24	RC01523000 MANOPOLA ELETTRICA TIMER SNACK GRIGIA	GREY TIMER KNOB
	24	RC01885000 MANOPOLA ELETTRICA TIMER SNACK NERA	BLACK KNOB FOR TIMER LINE SNACK 9,76

PAG. 1

Artic./Item	Descrizione/Description			Modello/Model	
126008	CUCINA ELETTRICA 4 PIASTRE CON FORNO ELETTRICO VENTILATO 4 HOT PLATES ELECTRIC RANGE WITH FAN ASSISTED ELECTRIC OVEN			PF70E/0	
Cons./Recom.	Pos./Posit.	Ricambio/Replacement			
	25	RC01524000	MANOPOLA ELETT.TERMOSTATO SNACK GRIGIA	SNACK GREY KNOB	
	25	RC01886000	MANOPOLA ELETT.TERMOSTATO SNACK NERA	BLACK KNOB FOR THERMOSTAT LINE SNACK	9,76
*	26	RC00052000	LAMPADA SEGN.NEON FASTON ARANCIO 230V	SIGNAL LAMP	5,19
	27	RC01602000	PIEDE 1"3/4 H250	FOOT	18,98
	30	RC00670000	FIANCO DX PF70/105EG	RIGHT SIDE PF70/105EG	109,78
	31	RC00671000	FIANCO SX PF70E/G	LEFT SIDE PF70E/G	49,58
	32	RC01889000	CRUSCOTTO BASE FORNO 60EL SNACK	CONTROL PANEL FOR OVEN 60EL SNACK	18,78
	501	RC02229000	MANIGLIA PSX ALLUMINIO	HANDLE	
	502	RC02230000	CRISTALLO PORTA E TNX 60 INOX	ESTERNAL DOOR GLASS	
	505	RC02231000	SPEZZONE SILICONE D.5 MM	DOOR RUBBER PART	
	506	RC02232000	CRIST PO E 60 TNX NERO	EXTERNAL GLASS OVEN DOOR	77,50
	507	RC02233000	CLIP BLOCCA VETRO INTERNO	DOOR INNER GLASS	4,76
*	508	RC02279000	SQUADRETTA BLOCCA VETRO	BRACKET SUPPORT	24,10
	509	RC02234000	CERNIERA PORTA FRG KG 6,0	DOOR HINGE	27,60
	510	RC02243000	GUARNIZIONE FACCIATA F60	OVEN GASKET	25,58
*	512	RC02280000	RESISTENZA CIRCOLARE 2 SP	FAN HEATING ELEMENT	37,96
	513	RC02281000	SQUADRETTA FISSA FORNO	BRACKET	
	514	RC02242000	SQUADRETTA SUPP. CERN. SX PORTA	LEFT HINGE PULLEY	
*	521	RC02282000	MOTOVENTILATORE	OVEN MOTOR-FAN	74,98
*	524	RC02283000	LAMPADA CON PORTALAMPADA	LIGHT BULB HOUSING	