




CODICI RICAMBIO PER FINITO / SPARE PARTS FOR THE FINISHED PRODUCT
Aggiornato al/Updated to 27/11/17

Artic./Item		Descrizione/Description			Modello/Model	
613064		PIANO COTTURA GAS 2 FUOCHI			EEC35G7	
		2 BURNERS GAS BOILING TOP				
Cons./Recom.	Pos./Posit.	Ricambio/Replacement			Prezzo/Price List	
	101	RC00376000	SUPPORTO PENTOLE SNACK	PAN GRID	80,98	
*	102	RC00128000	ACCENDITORE PIEZO CON DADO	PIEZO IGNITER	16,99	
*	103	RC00369000	RUBINETTO	GAS COCK	38,28	
	105a	RC01884000	MANOPOLA GAS SNACK NERA	BLACK KNOB FOR LINE SNACK	9,47	
	105b	RC02072000	MANOPOLA GAS SNACK GRIGIA	GREY KNOB	8,79	
*	108	RC00375000	COPERCHIO BRUCIATORE UR	COVER FOR "ULTRARAPID" BURNER	17,54	
*	109	RC01832000	SPARTIFIAMMA ULTRARAPIDO SNACK	SNACK ULTRARAPID BURNER COVER	34,58	
	110	RC00374000	GRUPPO VENTURI SPARTIFIAMMA UR	VENTURI GROUP (ULTRARAPID)	31,55	
*	112	RC00368000	CANDELETTA D'ACCENSIONE E MOLLA	SPARK PLUG	9,50	
*	113	RC00367000	TERMOCOPPIA L=600MM	THERMOCOUPLE FOR TOP BURNER	15,56	
*	114	RC00373000	COPERCHIO BRUCIATORE R	COVER FOR "RAPID" BURNER	7,83	
*	115	RC01833000	SPARTIFIAMMA RAPIDO SNACK	SNACK RAPID BURNER COVER	17,87	
	116	RC00372000	GRUPPO VENTURI SPARTIFIAMMA R	VENTURI GROUP (RAPID)	19,31	
	117	RC00377000	COPPA BRUCIATORE	BURNER CAP	7,83	
	119	RC01050000	CAMINO 350 L7	FLUE 350 L7	82,32	
	120	RC00311000	PIEDINO H=25 MM	FOOT	4,74	
	121	RC00304000	MORSETTO EQUIPOTENZIALE COMPLETO	EQUIPOTENTIAL CONNECTING BLOCK	6,62	