




**CODICI RICAMBIO PER FINITO / SPARE PARTS FOR THE FINISHED PRODUCT**
**Aggiornato al/Updated to 27/11/17**

| Artic./Item   |             | Descrizione/Description           |                                  |                                | Modello/Model     |  |
|---------------|-------------|-----------------------------------|----------------------------------|--------------------------------|-------------------|--|
| <b>613065</b> |             | <b>PIANO COTTURA GAS 4 FUOCHI</b> |                                  |                                | <b>EEC70G7</b>    |  |
|               |             | <b>4 BURNERS GAS BOILING TOP</b>  |                                  |                                |                   |  |
| Cons./Recom.  | Pos./Posit. | Ricambio/Replacement              |                                  |                                | Prezzo/Price List |  |
|               | 101         | RC00376000                        | SUPPORTO PENTOLE SNACK           | PAN GRID                       | 80,98             |  |
| *             | 102         | RC00128000                        | ACCENDITORE PIEZO CON DADO       | PIEZO IGNITER                  | 16,99             |  |
| *             | 103         | RC00369000                        | RUBINETTO                        | GAS COCK                       | 38,28             |  |
|               | 105a        | RC01884000                        | MANOPOLA GAS SNACK NERA          | BLACK KNOB FOR LINE SNACK      | 9,47              |  |
|               | 105b        | RC02072000                        | MANOPOLA GAS SNACK GRIGIA        | GREY KNOB                      | 8,79              |  |
| *             | 108         | RC00375000                        | COPERCHIO BRUCIATORE UR          | COVER FOR "ULTRARAPID" BURNER  | 17,54             |  |
| *             | 109         | RC01832000                        | SPARTIFIAMMA ULTRARAPIDO SNACK   | SNACK ULTRARAPID BURNER COVER  | 34,58             |  |
|               | 110         | RC00374000                        | GRUPPO VENTURI SPARTIFIAMMA UR   | VENTURI GROUP (ULTRARAPID)     | 31,55             |  |
| *             | 112         | RC00368000                        | CANDELETTA D'ACCENSIONE E MOLLA  | SPARK PLUG                     | 9,50              |  |
| *             | 113         | RC00367000                        | TERMOCOPPIA L=600MM              | THERMOCOUPLE FOR TOP BURNER    | 15,56             |  |
| *             | 114         | RC00373000                        | COPERCHIO BRUCIATORE R           | COVER FOR "RAPID" BURNER       | 7,83              |  |
| *             | 115         | RC01833000                        | SPARTIFIAMMA RAPIDO SNACK        | SNACK RAPID BURNER COVER       | 17,87             |  |
|               | 116         | RC00372000                        | GRUPPO VENTURI SPARTIFIAMMA R    | VENTURI GROUP (RAPID)          | 19,31             |  |
|               | 117         | RC00377000                        | COPPA BRUCIATORE                 | BURNER CAP                     | 7,83              |  |
|               | 119         | RC01051000                        | CAMINO 700 L7                    | FLUE 700 L7                    | 118,28            |  |
|               | 120         | RC00311000                        | PIEDINO H=25 MM                  | FOOT                           | 4,74              |  |
|               | 121         | RC00304000                        | MORSETTO EQUIPOTENZIALE COMPLETO | EQUIPOTENTIAL CONNECTING BLOCK | 6,62              |  |